



让中国制造成为全球顶级制造

MK series integrated (PLC+HMI)

User manual

Revision History

Date	Revision	Description
2025/03/21	MK_usermanual_V000	Initial revision
2025/04/14	MK_usermanual_V001	5.9.2 Update USB downloaded content

Manual Acquisition

This manual is only available in PDF format. Users can log into the Kinco official website (<https://en.kinco.cn/>) and going to "Services -> Download" to search for keywords and download the document.

Programming Software Acquisition

➤ PLC programming software — KincoBuilder

- KincoBuilder (compliant with the IEC 61131-3 standard) support both LD and IL programming languages. The software installation package for KincoBuilder can be obtained through the download service on the Kinco official website (<https://en.kinco.cn/download/plcsoftware.html>).
- The latest version of KincoBuilder always maintains compatibility with the functionalities of the old versions, but new PLC instructions and features require the use of updated software and firmware versions. To ensure a smooth experience, please promptly download the latest version of the programming software.

➤ HMI configuration editing software — KincoDTools

- The software installation package for KincoDTools can be obtained through the download service on the Kinco official website (<https://en.kinco.cn/download/hmisoftware.html>).

Safety Precautions

This chapter explains the safety precautions that need to be followed when using this product. Before using the product, please read the product manual and any associated manuals referenced in it to correctly understand the relevant safety information.




Failure to comply with the provisions of the safety precautions may result in death, serious injury, or equipment damage.







The "Danger," "Warning," and "Caution" items in the manual do not represent all safety precautions to be followed but serve as supplements to all safety precautions.

This product should be used in environments that meet the design specifications; otherwise, malfunctions may occur, and any abnormalities in function or component damage due to non-compliance with relevant regulations are not covered by the product quality guarantee.

Kinco will not be liable for any legal responsibility arising from personal safety accidents or property losses caused by non-compliance with the content of this manual

To ensure the safe use of the product, this manual uses the following symbols and graphics to indicate precautions and highlights safety-related important content. Please be sure to comply

	Danger Indicates dangerous behavior. Failure to take appropriate precautions may result in serious personal injury or death.
	Warning Indicates warning behavior. Failure to take appropriate precautions may result in serious personal injury or death.
	Caution Indicates general information or instructional behavior. Failure to heed the corresponding prompts may lead to unforeseen consequences.

When Power is Supplied	
	<ul style="list-style-type: none"> ❖ During power supply, do not touch any terminals or terminal blocks, and do not attempt to disassemble any units. Especially during power supply or just after power is turned off, capacitors need time to discharge, which may cause electric shock or other personal or equipment hazards.
During Assembly	
	<ul style="list-style-type: none"> ❖ Assembly, wiring, maintenance, and inspection of this product should all be conducted by professional personnel who have received relevant training in electrical equipment. ❖ Do not use PLC in the following places: environments with dust, oil fumes, conductive dust, corrosive gases, or flammable gases; exposure to high temperatures, condensation, wind, or rain; environments with vibration or impact. Electric shock, fire, or misuse may also result in product damage.
	<ul style="list-style-type: none"> ❖ During screw assembly or wiring, be careful not to allow metal shavings, dust, or wire ends to fall into the ventilation holes of the PLC. Otherwise, it may cause fire, malfunction, or unintended actions of the PLC.
Wiring	
	<ul style="list-style-type: none"> ❖ During power supply, do not touch any terminals or terminal blocks, and do not attempt to disassemble any units. Especially during power supply or just after power is turned off, capacitors need time to discharge, which may cause electric shock or other personal or equipment hazards. ❖ Before wiring operations, please ensure that all external power supplies to the system are completely disconnected. Otherwise, there is a risk of electric shock to personnel and equipment malfunction.
	<ul style="list-style-type: none"> ❖ After completing the installation and wiring operations, before energizing and operating the product, ensure that it is fully assembled (including end caps, plate covers, etc.), otherwise there may be a risk of electric shock. ❖ Cable terminals should be properly insulated to ensure that the insulation distance between cables does not decrease after the cables are installed on the terminal block. Otherwise, there is a risk of electric shock, short circuit, or equipment damage.
	<ul style="list-style-type: none"> ❖ During screw assembly or wiring, be careful not to allow metal shavings, dust, or wire ends to fall into the ventilation holes of the PLC. Otherwise, it may cause fire, malfunction, or unintended actions of the PLC. ❖ Before connecting relevant cable connections, confirm the type of interface to be connected. Incorrect wiring may lead to controller or external equipment malfunctions or damage. ❖ Tighten the bolts on the terminal block within the specified torque range. Loose terminal bolts may result in circuit shorts, disconnections, fires, and other hazards. Over-tightening the bolts may damage the bolts and the controller, leading to component detachment, circuit shorts, fires, and other hazards. ❖ When using connectors and connecting external devices, use the tools specified by the manufacturer for pressing, crimping, or correct soldering. Poor connections may lead to shorts, fires, and other hazards. ❖ Do not bundle control lines and communication cables with main circuit or power supply lines, or place them too close to each other. Control lines and communication cables should be arranged at least 100mm away from main circuit power lines in cable ducts or spaces to avoid interference

MK series integrated(PLC+HMI) user manual

due to electromagnetic noise.

- ❖ For applications with severe interference, use special shielded cables for high-frequency signal input or output to improve the system's anti-interference capability.

During System Design



- ❖ When applying, it is essential to design a safety circuit to ensure that the control system remains safe even in the event of a power failure or controller malfunction.
- ❖ If the output circuit experiences prolonged overcurrent due to exceeding the rated load current or load short circuits, the controller may smoke or catch fire. Therefore, external safety devices such as fuses or circuit breakers should be installed to interrupt power.



- ❖ It is crucial to set up emergency braking circuits, protection circuits, interlocking circuits for forward and reverse operations, and upper and lower limit interlock switches in the external circuits of the controller to prevent machine damage.
- ❖ To ensure safe equipment operation, design external protection circuits and safety mechanisms for significant accident-related output signals.
- ❖ When the controller's CPU detects abnormalities in its system, it may automatically shut off all output signals. Additionally, partial circuit failures in the controller may result in uncontrolled outputs.
- ❖ To ensure equipment's normal operation, suitable external control circuits need to be designed.
- ❖ Damage to the transistor output unit of the controller may render its output status uncontrollable.
- ❖ Programmable controllers should be designed for use in indoor electrical environments with overvoltage level II. The power supply system level should include lightning protection devices to prevent lightning-induced overvoltage from affecting the programmable controller's power input terminals, signal input terminals, control output terminals, and other ports, thus avoiding equipment damage.

During Operation and Maintenance



- ❖ Assembly, wiring, maintenance, and inspection of this product should all be conducted by professional personnel who have received relevant training in electrical equipment.
- ❖ Before cleaning or tightening the bolts on the terminal block or installing connector bolts, please ensure that the system's power supply is completely disconnected.



- ❖ Before making any online modifications to the program, forcing outputs, starting (RUN), or stopping (STOP) operations during equipment debugging, it is essential to thoroughly read the user manual. Only proceed with these operations after ensuring their safety.

Content

Revision History	2
Manual Acquisition	2
Programming Software Acquisition	2
Safety Precautions	3
1 General description	1
1.1 Product introduction	1
1.2 Product information	1
1.2.1 Naming rule	1
1.2.2 Nameplate information	2
1.3 Operating and Storage Conditions	3
1.4 Product List	4
2 Product overview and hardware description	6
2.1 Features introduction	6
2.2 Component and interface description	8
2.2.1 MK070E component description	8
2.2.2 MK043E-20DT component description	9
2.2.3 MK043E-27DT component description	10
2.2.4 MK series product dimension	11
2.2.5 Component function description	12
2.2.6 MK back interface and pin description	15
2.2.7 PLC function support description	18
2.2.8 CPU module technical specification	24
2.2.9 CPU power wiring diagram	27
2.2.10 DI/O wiring diagram	27
2.2.11 AI/O wiring diagram	29
2.2.12 MK series product wiring summary	34
2.2.13 MK series product dimension	39
3 Installation guideline	41
3.1 MK series product connect expansion module	41
3.2 Dis/Assembly of terminal blocks	42
3.2.1 Disassembly of terminal blocks	42
3.2.2 Assembly of terminal blocks	42
3.3 Installation method	43
4 Getting started with Kinco Builder	45
4.1 Software interface introduction	45
4.2 Create a New Project	46
4.3 Hardware configuration	47
4.3.1 Configure the CPU	47
4.3.2 Configure the expansion module	48
4.4 Programming simplified guide	49
4.4.1 On-line Help	49

4.4.2 Programming language	50
4.4.3 Programming instructions	50
4.5 Compiler and Simulator	51
4.5.1 Compiler	51
4.5.2 Simulator	52
4.6 Connection and program up/download	54
4.6.1 MK series PLC communicate with PC via USB-Slave	54
4.6.2 Program upload/download	55
4.7 Error message and solution	57
4.7.1 Error Message in KincoBulider	57
4.7.2 Common Error	57
4.8 Firmware update	58
5 Getting started with KincoDTools	61
5.1 KincoDTools create new project	61
5.1.1 Initial interface function description	62
5.2 KincoDTools system parameters set	65
5.2.1 Add/Delete HMI	66
5.2.2 Network device and serial port setting	66
5.3 Startup menu	69
5.4 Configuration Editor	69
5.4.1 Configuration editor window	69
5.4.2 KincoDTools user manual	70
5.4.3 Add component	71
5.4.4 Add frame	74
5.5 Macro	75
5.5.1 Create macro file	75
5.5.2 Add variable	76
5.5.3 Macro file compilation and use	76
5.6 Offline Simulation	78
5.7 Special register function	79
5.8 IOT function	80
5.9 Project download	80
5.9.1 Compile & Download	80
5.9.2 Flash drive download PLC program	83
5.10 KDManger	85
5.10.1 Download/Upload Operate	86
5.10.2 System Operate	87
5.10.3 Get Version	88
5.10.4 Decompile Operate	89
5.10.5 Decrypt Operation	90
5.10.6 Through communication method	91
6 Services and Support	92
6.1 Services	92
Agents and Offices	92
6.2 Contact Us	92
7 Appendix	93

7.1 Fast selection list93

1 General description

1.1 Product introduction

Kinco MK series product combine the advantages of HMI+PLC+ iot technology.It is an economical integrated product that supports the iot function.


MK series adopts high-performance CPU and applies the new DTools software technology platform while retaining the high cost-effectiveness of the HP series all-in-one machine, which can support more rich picture components and functions. In addition, combined with the kinco machine iot platform to provide remote download, transparent PLC, VNC monitoring, device management and other remote operation and maintenance functions to provide more value to the majority of users.

1.2 Product information

1.2.1 Naming rule

The naming rules for product models are as follows:

Module type + Number of channels + function identification , as shown in figure:



In the MK series, except the MK070E-32DX body has no analog, other models body have analog input / output. In addition, the MK043E-27DT body has a 4-channel DIO, which can be used as a drain type DI input or source type DO output according to the connection method.

According to the above principles, MK070E - 33DT stands for the DC 24 V power supply, the total input/output channels is 33 (16*DI , 14*DO , 2*AI , 1*AO) of 7 inch integrated machine; MK043E-20DT stands for the DC 24 V power supply, the total input/output channels is 20 (9*DI , 9*DO , 2*AI) of 4.3 inch integrated machine.

1.2.2 Nameplate information



NO.	Decription
①	EAC certification
②	Model
③	The 1st~6th codes indicate product code, which ensures uniqueness for different models.
	The 7th~8th codes indicate the production year, indicating the year of production (e.g., "17" for 2017) .
	The 9th~11th codes indicate the production day, indicating the day of production within the year (e.g., "148" for the 148th day of the year).
	The 12th~16th codes indicate the production sequence of the product on that particular day, indicating the sequential order of production for products of the same model on that day (e.g., "001" for the first product).
④	Product serial number barcode
⑤	CE certification
⑥	RoHS certification

1.3 Operating and Storage Conditions

The MK series products complies with the GB/T 15969.3-2007 (equivalent to IEC61131-2:2007) standard and testing specifications.

Transportation and Storage		
Environmental conditions	Temperature	-40°C ~ +70°C
	Relative humidity	10% ~ 95%, non-condensing
	Atmospheric pressure	Altitude of 0 ~ 3000 meters above sea level
Mechanical conditions	Free fall	With transportation packaging, allowed to fall 5 times from a height of 1 meter onto a cement surface.
Operating conditions		
Environmental conditions	Temperature	Naturally ventilated open device, -10 ~ 55°C
	Relative humidity	10% ~ 95%, non-condensing
	Atmospheric pressure	Altitude not exceeding 2000 meters
	Pollution Level	Level 2
Mechanical conditions	Sinusoidal vibration	5<f<8.4Hz: Random vibration displacement: 3.5mm Continuous vibration displacement: 1.75mm 8.4<f<150Hz: Random vibration acceleration: 1.0g Continuous vibration acceleration: 0.5g
	Shock	Half-sine wave, 15g, 11ms, six times per axis
Electromagnetic Compatibility (EMC)	Electrostatic discharge	Air discharge: 8KV Withstands Contact discharge: 4KV Withstands Level B
	Surge	AC power supply: 2KV CM, 1KV DM DC power supply: 0.5KV CM, 0.5KV DM IO and communication interface: 1KVCM Level B
	EFT (Electrical Fast Transient)	Power supply coupling: 2KV, 5KHz IO and communication coupling: 1KV, 5KHz Level B
	Voltage dip	AC system, at 50Hz, voltage drop to 0% for 1 cycle, 40% for 10 cycles, 75% for 20 cycles. Level A
Ingress protection	Waterproof and dustproof	IP20

1.4 Product List

Standard product		MK070E-33DT	MK070E-32DX	MK043E-20DT
Power supply		DC24V （Range： DC 20.4V-DC 28.8V）		
DI/DO	DI	16*DC24V(PNP/NPN)	16*DC24V （PNP/NPN）	9*DC24V(PNP/NPN)
	DO	14*DC24V(PNP)	4*DC24V(PNP) 12*Relay	9*DC24V(PNP)
	DIO	/	/	/
AI/AO	AI	2*AI	/	2*AI Support 0-10V signal
	AO	1*AO	/	/
Interface	Programmatic interface	USB-Slave/RS485(Port1)		
	CAN	1*CAN,support CAN free communication		
	Serial communication	2*RS485		
Expansion module		Supports 8 KS series extensions		
Screen size		7"TFT		4.3"TFT
Screen quality	Resolution ratio	800*480 pixel resolution		480*272 pixel resolution
	Colour	256K color		
	Brightness	250cd/m^2		
HMI type		4-wire precision resistance network touch screen		
Interface	Ethernet	10M/100M adaptive Ethernet interface, can download HMI configuration program		
	USB-Host	Supports extended memory and external device		
	USB-Slave	PLC, HMI program download interface		

Note:

- ❖ DC24V of DI and DO in the table indicates the transistor type, and Relay indicates the relay type.
- ❖ The AI/AO rows in the table supports 4-20mA/1-5V/0-20mA/0-10V signals.

Standard product		MK070E-27DRT	MK043E-20DTC	MK043E-27DT
Power supply		DC24V （Range： DC 20.4V-DC 28.8V）		
DI/DO	DI	12*DC24V(PNP/NPN)	9*DC24V(PNP/NPN)	10*DC24V(PNP/NPN)
	DO	12*Relay	9*DC24V(PNP)	10*DC24V(PNP)
	DIO	/	/	4*DC24V Change the input/output function of each channel according to the wiring, can be mixed
AI/AO	AI	3*RD Support Pt100 thermal resistance, temperature measuring range -40°C-240°C	2*TC Support J/K/E/T thermocouples	2*AI
	AO	/	/	1*AO
Interface	Programmatic interface	USB-Slave/RS485(Port1)		
	CAN	1*CAN,support CAN free communication		
	Serial communication	2*RS485		
Expansion module		Supports 8 KS series extensions		
Screen size		7"TFT		4.3"TFT
Screen quality	Resolution ratio	800*480 pixel resolution		480*272 pixel resolution
	Colour	256K color		
	Brightness	250cd/m^2		
HMI type		4-wire precision resistance network touch screen		
Interface	Ethernet	10M/100M adaptive Ethernet interface, can download HMI configuration program		
	USB-Host	Supports extended memory and external device		
	USB-Slave	PLC, HMI program download interface		

Note:

- ❖DC24V of DI and DO in the table indicates the transistor type, and Relay indicates the relay type.
- ❖The AI/AO rows in the table supports 4-20mA/1-5V/0-20mA/0-10V signals.

Economy product		MK070C-33DT	MK043C-20DT
Power supply		DC24V （Range： DC 20.4V-DC 28.8V）	
DI/DO	DI	16*DC24V(PNP/NPN)	9*DC24V(PNP/NPN)
	DO	14*DC24V(PNP)	9*DC24V(PNP)
AI/AO	AI	2*AI	2*AI Support 0-10V signal
	AO	1*AO	/
Interface	Programmatic interface	USB-Slave/RS485(Port1)	
	CAN	Not supported	
	Serial communication	1*RS485(Port1)	
Expansion module		Not supported	
Screen size		7"TFT	4.3"TFT
Screen quality	Resolution ratio	800*480 pixel resolution	480*272 pixel resolution
	Colour	256K color	
	Brightness	250cd/m^2	400cd/m^2
HMI type		4-wire precision resistance network touch screen	
Interface	Ethernet	-	
	USB-Host	Supports extended memory and external device	
	USB-Slave	PLC, HMI program download interface	

Note:

❖DC24V of DI and DO in the table indicates the transistor type.

❖The AI/AO rows in the table supports 4-20mA/1-5V/0-20mA/0-10V signals.

2 Product overview and hardware description

2.1 Features introduction

- ❖ Built-in iot function, support program upload/download, transparent PLC, VNC monitoring, equipment management and other rich remote operation and maintenance functions, easy to use and powerful in functionality, taking into account the application needs of customers in various occasions.

- ❖ The HMI part adopts industrial CPU, 700MHz main frequency, 128MB Flash+64MB DDR2 large-capacity storage, and supports Kinco new generation of HMI DTools programming software to further improve product performance.

- ❖ The standard body are equipped with 10/100M adaptive Ethernet port, which can access Ethernet devices and support USB extended storage, the MK043E-27DT adopts Type-C interface as the programming port and is compatible with common Type-C mobile phone data cable, which provides convenience for users to program and debug the device.

- ❖ Four DIO have been added to the PLC section of MK043E-27DT, which can be used as both DI and DO, simply follow the corresponding wiring method and no other configuration is required. An RS232 serial port has been added to the display section for direct data exchange with external devices

- ❖ MK series support a variety of expansion modules, standard product can expand 8 KS expansion modules, meeting users' various application needs and offering higher cost-effectiveness.

- ❖ Provide 4 high-speed pulse outputs, all supporting PTO (pulse train) and PWM (pulse width modulation) output modes. KincoBuilder software provides PLS (PWM or PTO), positioning control command group, PFLO_F (follow command), etc., making it convenient for users to implement simple motion control applications.

- ❖ In addition to the economy model, the other models include two RS485 interfaces (Port1 and Port2), with a maximum communication rate of 115.2kbps, of which Port1 supports programming protocols, Modbus RTU master station, slave station and free communication functions. Port2 supports Modbus RTU master station, slave station, and free communication.

- ❖ KincoBuilder software provides easy to use motion control commands, the software is equipped with motion control wizard function to help users get started with zero threshold, fast configuration, efficient programming.

2.2 Component and interface description

2.2.1 MK070E component description



Note:


❖MK070E-33DT/MK070E-32DX/MK070E-27DRT components are the same, only the total number of input and output points are different

No.	Name	Function
①	Display and touch LCD screen	Display and touch area
②	Status indicator light	Indicate current status of the MK
③	Digital output channel terminal	Used for connecting digital output signal, the wiring is fastened with screws, and the terminals are detachable
④	Digital input channel terminal	Used for connecting digital input signal, the wiring is fastened with screws, and the terminals are detachable
⑤	Analog output channel terminal	Used for connecting analog output signal, the wiring is fastened with screws, and the terminals are detachable
⑥	Analog input channel terminal	Used for connecting analog input signal, the wiring is fastened with screws, and the terminals are detachable
⑦	Power terminal	Access DC24V power supply
⑧	DB9 interface	Supports 2*RS485 (Port1, Port2) and KS extension

MK series integrated(PLC+HMI) user manual

⑨	USB Host interface	HMI expansion interface for peripheral devices such as storage devices, keyboards, or mouse
⑩	CLR button	PLC program clears physical key
⑪	Ethernet interface	For Ethernet communication connection, can connect to PC to view HMI information and download configuration program
⑫	USB Slave interface	Connect to PC to view MK information, download PLC program and HMI configuration program
⑬	Sealing ring	To prevent dust or fine particles from entering the installation gap, the sealing ring can be removed

2.2.2 MK043E-20DT component description



No.	Name	Function
①	Display and touch LCD screen	Display and touch area
②	Digital output channel terminal	Used for connecting digital output signal, the wiring is fastened with screws, and the terminals are detachable
③	Digital input channel terminal	Used for connecting digital input signal, the wiring is fastened with screws, and the terminals are detachable
④	Power terminal	Access DC24V power supply
⑤	Analog input channel terminal	Used for connecting analog input signal, the wiring is fastened with screws, and the terminals are detachable
⑥	DB9 interface	Supports 2*RS485 (Port1, Port2) and KS extension

MK series integrated(PLC+HMI) user manual

⑦	USB Host interface	HMI expansion interface for peripheral devices such as storage devices, keyboards, or mouse
⑧	CLR button	PLC program clears physical key
⑨	Ethernet interface	For Ethernet communication connection, can connect to PC to view HMI information and download configuration program
⑩	USB Slave interface	Connect to PC to view MK information, download PLC program and HMI configuration program
⑪	Sealing ring	To prevent dust or fine particles from entering the installation gap, the sealing ring can be removed

2.2.3 MK043E-27DT component description




No.	Name	Function
①	Display and touch LCD screen	Display and touch area
②	Digital output channel terminal	Used for connecting digital output signal, the wiring is fastened with screws, and the terminals are detachable
③	Digital input channel terminal	Used for connecting digital input signal, the wiring is fastened with screws, and the terminals are detachable
④	Power terminal	Access DC24V power supply
⑤	Analog output channel terminal	Used for connecting analog output signal, the wiring is fastened with screws, and the terminals are detachable
⑥	DIO channel terminal	According to the corresponding connection mode, as DI, DO single or mixed use, the wiring is fastened with screws, and the terminals are detachable

MK series integrated(PLC+HMI) user manual

⑦	Analog input channel terminal	Used for connecting analog input signal, the wiring is fastened with screws, and the terminals are detachable
⑧	DB9 interface	Supports 2*RS485 (Port1, Port2) and KS extension
⑨	USB Host interface	HMI expansion interface for peripheral devices such as storage devices, keyboards, or mouse
⑩	CLR button	PLC program clears physical key
⑪	Ethernet interface	For Ethernet communication connection, can connect to PC to view HMI information and download configuration program
⑫	USB Slave interface	Connect to PC to view MK information, download PLC program and HMI configuration program
⑬	Sealing ring	To prevent dust or fine particles from entering the installation gap, the sealing ring can be removed

2.2.4 MK series product dimension



Model	MK070E	MK043E-20DT/MK043E-20DTC	MK043E-27DT
Installation dimension L*W (mm)	192*138	119*93	119*93
Boundary dimension L*W*H (mm)	204*150*33.9	132*102*31.5	132*102*45.42


The L, W and H marked in the figure are the first letters of Length, Width and Height respectively. Installation dimension refer to the dimension required for the MK to be installed on other components, as indicated by the red box in the diagram. Boundary dimension refer to the dimension of the length, width and height of the outermost edge of the MK.

2.2.5 Component function description

2.2.5.1 Status indicator light

In the MK series, only the 7-inch integrated machine is equipped with a status indicator light on the panel. According to the user's usage and feedback, the panel indicator light has been updated twice, and the differences before and after the update will be explained below.

There are three types of indicator lights on the MK series panel: PWR, RUN, and STA, which are used to indicate the current operation status of MK.

	<p>[PWR] : Power status indicator light. When the power supply is normal, the PWR light turn on (green).</p> <p>[RUN] : PLC operating status indicator light. It turn on (green) during normal operation.</p> <p>*[STA] : PLC error indicator light, the latest panel indicator light, When an error is detected in the user program or CPU , the STA light will turn on (blue).</p> <p>*[Err] : PLC error indicator light, the old panel indicator light, When an error is detected in the user program or CPU , the Err light will turn on (red).</p> <p>*[Com] : Communication status indicator light, initial panel indicator light, When either communication port (Port1/Port2) is used for receiving or transmitting, the COM light will blink (green).</p>
---	---

● Indicator light status description

Indicator light	Color	Status	Description
PWR	Grey (off) / Green(on)	Light keeping on	Power supply normal
		Off	Power supply is abnormal or disconnected
Run	Grey (off) / Green(on)	Light keeping on	PLC is in running status
		Blink	PLC is in firmware update mode
		Off	PLC not running
STA	Grey (off) / Blue(on)	Light keeping on	User program or PLC has encountered an error
		Off	No error detected by PLC
Err. [Old indicator light]	Grey (off) / Red(on)	Light keeping on	User program or PLC has encountered an error, user can view the specific error through KincoBuilder
		Off	No error detected by PLC
COM [Old indicator light]	Grey (off) / Green(on)	Blink	Any communication port is in the receiving or sending state
		Off	The current COM port is not working

The CPU categorizes errors into three levels: fatal error, critical error, and general error. When the CPU detects an error, STA indicator light on and stores the specific error codes in order of occurrence. Users can view the specific error information through the KincoBuilder programming software for analysis. For specific fault analysis, please refer to **section 4.7 Error Information and Handling**

Error type	Run	Err.	Description
Fatal error (Access security subsystem)	OFF	Blink	<p>When a fatal error occurs, the PLC will immediately exit the normal scanning state, and according to the value of the special register SM2.0 to determine whether to directly reset the PLC or enter the independent security subsystem operation:</p> <ul style="list-style-type: none"> ➤ If the SM2.0 = 0, the PLC will enter the independent security subsystem operation after a fatal error ➤ If the SM2.0 = 1, the PLC will be reset and restarted directly after a fatal error. ➤ The default value of the special register SM2.0 after power on is 0 <p>*PLC in the security subsystem state will enter the state of unable to communicate and use. *When entering the security subsystem due to a user program running error, the PLC can be restored to normal operation status through the [Tools] → [Clear (for fatal errors state)] in the menu bar or the CLR button. *If the PLC enters the safety subsystem due to hardware damage or firmware bug, it cannot be restored to normal operation through clearing and CLR key</p>
Critical error	OFF	Light keeping on	A critical error in the PLC will prevent the user program from continuing to run correctly, but the result is predictable.
General error	Light keeping on	Light keeping on	General error occurs when a PLC performs a certain function, but other parts of the program can continue to run with predictable results.




Figure 2.2.5-1 PLC information and errors

The CPU has two main states: Run and Stop. In the running state, the CPU module executes the main scanning task and various interrupt tasks in a normal cycle. In the stopped state, the CPU module only processes some communication requests (including programming, debugging, and other commands from the KincoBuilder software, as well as communication commands from the Modbus RTU slave station in response to the master station), and immediately outputs all output points (DO, AO) to the "shutdown output" value defined in the [hardware configuration] of the user project.

- Change CPU state method

In general, when the PLC is powered on and online normally, PLC default state is the startup state. Users can change the CPU state through KincoBuilder:

- Connect the CPU module to the PC, refer to **KincoBuilder hardware configuration and connection and program upload /download**
- In KincoBuilder software menu bar execute [Debug] → [Start PLC] Or [Stop PLC] menu command




Figure 2.2.5-2 Switching PLC status

Note:

- ❖ If the PLC detects a serious error during operation, it will immediately enter the stop state.
- ❖ If the PLC fails to download the program midway, the PLC will maintain the software-controlled STOP state.

2.2.5.2 CLR program clear physical key

In order to avoid the PLC crash caused by program logic error, the CLR key is set behind the MK, which is used to clear the user program inside the PLC and restore normal operation when a fatal error occurs during program operation and enters the safety subsystem. The steps to clear the PLC user program using physical key are as follows:

1. After pressing the key, it will enter the pre-clear state after about 5s, at this time, the STA light turns on and off with a cycle of 2s, if the user has been pressing the key, it will be maintained in this state;
2. Release the key (at least 2s), and enter the state of waiting for user confirmation. At this time, the STA light turns on and off with a cycle of 600ms. If the user releases the key for more than 60s, PLC will completely exit the program clearing function and return to the state before pressing the key.
3. Press the button (at least 5s) for user confirmation, and the PLC begins to clear the internal user program.

When the PLC clears the internal user program, the STA light is keeping on, the PLC does not respond to any other action, if the clearance is successful, the STA light is on and off twice for a cycle of 2s, if the clearance fails, the STA light is on and off for 4 times for a cycle of 1s. After successfully clearing the user program, it is necessary to power off and restart the PLC within 60s, otherwise it is necessary to perform the above clearing steps again.

Considering the factors of preventing mechanical shaking and user misoperation, the CLR key can be pressed and released in each of the above steps, without affecting the function, and the user can operate with confidence.

2.2.6 MK back interface and pin description

2.2.6.1 DB9 interface

The DB9 interface behind the MK provides 2*RS485 (Port1, Port2) communication, both support ModbusRTU master/slave station, free communication function, of which Port1 can be connected to download programs. EX. indicates an expansion port that supports a maximum of 8 KS expansion modules. DB9 interface of some MK models support different communication protocols, and you need to correctly connect pins based on the wiring diagram of the model.

The following figure shows the pin numbers of the DB9 interface. In addition, there are pin number marked with silk screen printing on the DB9 female port (as shown in the figure), user can use light to view the corresponding pin number.




Figure 2.2.6-1 DB9 interface



Figure 2.2.6-2 DB9 interface silk screen printing

The following table shows the ports, pin numbers, and meanings used by each communication protocol in the DB9 interface. It should be noted that COM2 is only supported in DB9 interfaces of the MK043E-27DT model.

Protocol interface	Pin	Signal	Meaning
Port1 (RS485)	6	A	RS485 signal, TXD+/A
	1	B	RS485 signal, TXD-/B
Port2 (RS485)	9	A	RS485 signal, TXD/A
	4	B	RS485 signal, TXD/B
CAN	7	CAN_H	CAN bus signal, high level
	2	CAN_L	CAN bus signal, low level
COM2 (Only MK043E-27DT)	3	RXD	Rceive data
	8	TXD	Send data
GND	5	GND	Ground

The bus topology structure of RS485 is shown in the following figure. It is recommended that the customer connect a 120Ω terminal resistor to the first and last ends of the bus when in use.





Figure 2.2.6-3 RS485 topology structure


2.2.6.2 USB-Host interface

The USB-Host interface enables the HMI to connect to external devices. Users can connect to external storage devices, a mouse, or a keyboard, providing various information input methods. For details about how to set the parameters on the DTools software, see **5.4.2 KincoDTools user manual**.

<div><div>GND D+ D- 5V</div><div></div><div>4 3 2 1</div><div>USB-Host</div></div> <tr><th>Pin</th><th>Signal</th><th>Description</th></tr> <tr><td>1</td><td>5V</td><td>USB power supply</td></tr> <tr><td>2</td><td>DATA-</td><td>USB data signal negative</td></tr> <tr><td>3</td><td>DATA+</td><td>USB data signal positive</td></tr> <tr><td>4</td><td>GND</td><td>Ground</td></tr>	Pin	Signal	Description	1	5V	USB power supply	2	DATA-	USB data signal negative	3	DATA+	USB data signal positive	4	GND	Ground
	Pin	Signal	Description												
	1	5V	USB power supply												
	2	DATA-	USB data signal negative												
	3	DATA+	USB data signal positive												
4	GND	Ground													


2.2.6.3 EtherNet interface

The MK series CPU module is equipped with a 10/100M Ethernet port (in accordance with the IEEE802.3 standard specification), in the form of RJ45. Users can access the external network or other Ethernet device, the interface supports programming protocols, can download the HMI configuration program

	Indicator light	Color	Status	Description
	Green light	Gray green (off) /Green (on)	Light keeping on	100M communication connection
			Off	10M communication connection
			Blink	Data is being sent and received
			Light keeping on	No data is being sent or received

The default factory IP address of the MK CPU module is 192.168.0.252. User can use the ethernet interface to communicate with HMI through KincoDTools. For the communication configuration, see **4.6.1 MK series PLC communicate with PC via USB-Slave**.

EtherNET interface communication cable using direct cable or cross cable. The Ethernet interface on the CPU module provides the "auto negotiation" function. When a cable is inserted, it automatically negotiates with the communicate device to determine the cable type to be used.

	Pin	Signal	Description
	1	TD+	Send+
	2	TD-	Send-
	3	RD+	Receive+
	4		
	5		
	6	RD-	Receive-
	7		
	8		

2.2.6.4 USB-Slave (USB-B&Type-C)

USB-Slave is the PLC, HMI general program download interface, in the MK series only MK043E-27DT USB-Slave uses the Type-C interface, the use of mobile phone data cable can be connected to download programs, other MK models use USB-B interface.

After the programming data cable is connected to the computer, the virtual serial port is created on the computer for communication. Each version of Windows10 and Windows11 comes with the USB driver of the KPLC part. The user does not need to install the driver. The computer system before Win10 needs to install the driver before it can be used. In general, when using the programming data cable to connect the device and the computer, the Windows system will automatically detect the new hardware and prompt the installation of the driver. If there is no corresponding prompt, the \Drivers folder in the KincoBuilder installation directory contains driver programs that support Windows XP, Windows 7, and Windows 8 systems. Users can choose the driver program according to their own Windows version for installation.

The USB driver is also stored in \Drivers in the installation directory of KincoDTools. User need to manually install the USB driver in the **Hardware Update Wizard** dialog box that is automatically displayed on the PC operating system.

For communication configuration, see **4.6 Connection and program upload/download**.



Figure 2.2.6-4 USB-B data cable




Figure 2.2.6-5 USB-B pin number

Pin	Signal	Description
1	5V	USB power supply
2	DATA-	USB data signal negative
3	DATA+	USB data signal positive
4	GND	Ground

2.2.6.5 Anti-demolition warranty label

There is an anti-demolition warranty label on the side of the MK series plc, which is the main basis for users and maintenance personnel to confirm whether the product is dismantled. If the user destroys the anti-demolition warranty label, it will be regarded as artificial damage, so it is not within the scope of warranty. The relevant after-sales service terms can be logged in the official website of kinco and viewed in **Services** → **After-sales service** → **Terms and conditions**




Figure 2.2.6-6 anti-demolition warranty label

2.2.7 PLC function support description

2.2.7.1 Data maintain and permanent storage

Data maintain refers to the ability to retain data stored in random-access memory(RAM) even after the CPU loses power, preserving the data in the same state it was before the power loss, then available for the CPU to use when it powers up again. **The data retention function** relies on a backup battery (CR2032) provided within the CPU to maintain power and preserve the data stored in RAM memory after a power outage. Operating with internal RAM provides fast read/write speeds and unlimited memory lifespan. However, once the battery is depleted, all data will be lost, so user needs to pay attention to the backup battery power situation. User can through the special register SM 0.7 to monitor the battery voltage is normal (SM0.7= TRUE, low battery voltage; SM0.7= FALSE, the battery voltage is normal). Under normal temperature conditions data retention can last for a cumulative period of at least 3 years.

User needs to use KincoBuilder software to select the data area type (such as V area, C area, start address, length, etc.) to be maintained in the user project [PLC hardware configuration]. The maximum data retention for the MK series V area is 1908 bytes (VB0~VB1907), and the maximum data retention for the C area is 64 bytes (C0~C63). For details, see **2.2.8.8 Program storage and RTC**.




Figure 2.2.7-1 Data maintain setting

Permanent storage refers to a designated area in the CPU's non-volatile memory (E2PROM) .The data stored in this area will not be lost even when power is disconnected. However,the E2PROM has limitations in terms of lifespan and write speed, so frequent or rapid writesshould be avoided.

The K series PLC provide a permanent data storage area within the V area. The data in this area will be automatically written to the EEPROM, and you can directly utilize these areas during programming. For the MK series PLC, it supported data backup areas are VB3648-VB3902 andVB3648-VB4905.

Figure 2.2.7-2 Permanent storage setting

Project	Meaning
Compatible with K3 (VB3648-VB3902)	This option indicates that VB3648-3092 will be activated as the data backup area,and the data in this area will be automatically written into pemanent storage(EEPROM).
Compatible with K5 (VB3648-VB4095)	This option indicates that VB3648- 4905 will be activated as the data backup area,and the data in this area will be automatically written into pemanent storage(EEPROM).
Compatible with K6 (VB15360-VB16383)	This option indicates that VB15360-16383 will be activated as the data backup area,and the data in this area will be automatically written into pemanent storage(EEPROM)
All of the above areas are used	This option indicates that VB3648- 4095 and VB15360-16383 wil be activatedtogether as the data backup area, and the data in this area will be automatically written into pemanent storage(EEPROM)
All of the above areas are Not used	This option indicates that no permanent storage area will be configured.

Note:

- ❖The erase/write lifespan of the EEPROM is 1 million times(1 ,000,000). Therefore, data with high-frequency changes should not be stored in the addresses of the permanent storage area.

2.2.7.2 Real-time clock

The MK series PLC integrates a real-time clock (RTC), providing real-time time/calendar display. The format of the real-time clock/calendar (year/month/day, hour/minute/second) is encoded in BCD format, automatically adjusting for leap years. When the CPU is powered off, the real-time clock relies on backup battery power to maintain operation. At room temperature, the typical lifespan of the battery is 5 years, with a cumulative retention time of no less than 3 years in a power-off state.

When using the RTC for the first time, you need to set the clock by executing the [PLC]-[Adjust CPU Clock...] menu command in KincoBuilder. After that, the READ_RTC, SET_RTC, RTC_W, and RTC_R instructions can be used to implement related control functions.




Figure 2.2.7-3 Adjust CPU clock

The real-time clock (RTC) function of the HMI part adopts BIN encoding format to provide real-time time and calendar display, and users can modify the time by entering the system Settings interface or special registers (LW10000-LW10006). If you need to synchronize the HMI display time with the PC time, this topic describes a simple time synchronization method. For more details, see **2.7 Clock Setting** in the **KincoDTools user Manual**.

Time synchronization through KManager

Open KManager, click [System Operate] on the left, then click [Set] to enter the Communication set and click [OK] after setting, finally click the [Synchronization system time].




Figure 2.2.7-4 KManager communication set




Figure 2.2.7-5 KManager synchronizing system time

The preceding operation must be performed after the PC is successfully connected to the HMI.

Backup battery

The MK series CPU uses a specific specification lithium battery as the backup battery. When CPU is power off, the backup battery is used to power the real-time clock to maintain its operation and also powers the RAM to retain data.

When the battery level is low, there will be an alarm message in KincoBuilder under [PLC Information]-[General Errors] prompting the user to replace the backup battery.

The backup battery can't be rechargeable and it requires removing the cover for replacement. After opening the cover, the battery as shown in the diagram on the right, you can see and replace. The battery is a lithium battery (CR2032, 3V). You can order the battery separately; for detailed ordering information, please contact the sales service center.



Battery replacement method

- ❖ Remove the terminal of each channel, remove the hex socket head cap screw, and cut or tear off the warranty label on the side, so you can remove the rear cover.
- ❖ After opening the cover, you will see the RTC battery on the upper circuit board. To ensure the battery's stability, it is typically fixed with electronic adhesive silicone gel after installation. At this point, you need to remove the adhesive used for fixation.
- ❖ Use a screwdriver or finger to pry the battery connector male and pull it out.
- ❖ Install the new battery connector male on the female socket of the circuit board, tear off the sponge sticker on the battery, and secure the battery in the proper position.
- ❖ Finally, in order to stabilize the battery, please put silicone on the battery connector to fix it.

Note:

❖ Please follow local waste disposal and recycling regulations for proper disposal of the old lithium battery.

2.2.7.3 High speed counting function

The MK series CPU support 4 high-speed pulse counters.numbered HSC0 to HSC3, covering single-phase /two-phase (UP/Down)/AB (1 multiple frequency and 4 multiple frequency) equal counting modes. The maximum counting frequency of MK series CPU each model is as follows:

Single-phase		AB single	
HSC0 and HSC1	HSC2 and HSC3	HSC0 and HSC1	HSC2 and HSC3
50KHz	50KHz	50KHz	50KHz
50KHz	50KHz	50KHz	50KHz

Each channel operation mode and hardware allocation

HSC0					
Model	Description	I0.1	I0.0	I0.5	
0	Single-phase up/down counter with internal direction control Direction control bit: SM37.3	Clock			
3	Single-phase up/down counter with external direction control	Clock		Direction	
6	Dual-phase counter with up/down counting clock	Clock (decrease)	Clock (increase)		
9	AB phase quadrature counter	Clock-A	Clock-B		
HSC1					
Model	Description	I0.4	I0.6	I0.3	I0.2
0	Single-phase up/down counter with internal direction control Direction control bit: SM47.3			Clock	
1		Reset			
3	Single-phase up/down counter with external direction control			Clock	Direction
6	Dual-phase counter with up/down counting clock			Clock (decrease)	Clock (increase)
9	AB phase quadrature counter			Clock-A	Clock-B
10		Reset			
HSC2					
Model	Description	I0.4		I0.5	
0	Single-phase up/down counter with internal direction control Direction control bit: SM57.3			Clock	
9	AB phase quadrature counter	Clock-B		Clock-A	
HSC3					
Model	Description	I0.6		I0.7	
0	Single-phase up/down counter with internal direction control Direction control bit: SM127.3			Clock	
9	AB phase quadrature counter	Clock-B		Clock-A	

2.2.7.4 High pulse speed output function

MK series PLC supports 4 high-speed pulse output channels, namely Q0.0, Q0.1, Q0.4, Q0.5, all channels support PTO (pulse string, pulse + direction) and PWM output. At the same time, the software provides PLS (PWM or PTO), positioning control instruction group, PFLO_F (follow instruction), etc., which is convenient for users to realize simple motion control applications.

There are two ways to use a high-speed counter:

1.Programming with relevant instructions: This method requires setting corresponding control registers in the program and calling the HDEF instruction and HSC instruction for programming. It is suitable for both single-segment PV setting mode and multi-segment PV setting mode. For more detailed guidance, please refer to the programming manual.




Figure 2.2.7-6 High speed counter instruction

2.Configuration with HSC wizard: This method is simple and intuitive, requiring only to check the settings provided in the wizard. It is suitable for both single-segment PV setting mode and multi-segment PV setting mode. It is recommended to use the wizard for setting, which is simple and convenient to save programming time.




Figure 2.2.7-7 High speed counter HSC wizard

Hardware channel allocation

Model	Definition	Channel 0	Channel 1	Channel 2	Channel 3
PTO (Pulse train)	Output	Q0.0	Q0.1	Q0.4	Q0.5
PTO (Pulse + direction)	Pulse output	Q0.0	Q0.1	Q0.4	Q0.5
	Direction output	Q0.2	Q0.3	Q0.6	Q0.7
PWM	Output	Q0.0	Q0.1	Q0.4	Q0.5

2.2.7.5 Interrupt function

MK series PLC body input point I0.0 ~ I0.3 support edge interrupt function, can use the input signal rising edge and falling edge to generate interrupt. This feature is fast enough to capture the rising or falling edge of the input, and to achieve a fast response to some input signals whose pulse width is less than the CPU scan cycle. For more detailed guidance and examples, please refer to the programming manual.

2.2.7.6 RS485

The MK series CPU all provide 2 channels of RS485, named PORT1 and PORT2. All channels are designed with isolation in hardware to ensure stable and reliable communication operation. The supported protocols or functionalities for RS485 ports are as follows ("√" indicate support, "-" indicate not support):

NO.	Modbus RTU	Programming&Debug	Free communication
PORT1	√	√	√
PORT2	√	×	√

Supports setting slave addresses from 1 to 127, with the default address being 1.

Supports baud rates ranging from 1200bps to 115200bps.

Supports master/slave mode.

Each channel can connect up to 32 devices.

2.2.8 CPU module technical specification

2.2.8.1 Power supply

Rated power supply	DC24V, USB-Slave only supports power supply during program debugging
Supply voltage range	DC20.4V~28.8V
Rated power	10W

2.2.8.2 DI

Input type	NPN/PNP
Rated input voltage	DC24V, maximum allowable DC30V
Rated input current	3.5mA@24VDC
Logic "0" maximum input voltage	5V@0.7mA
Logic "1" minimum input voltage	11V@2.5mA
Input delay time	Turn-on delay: common channel 15μs, high-speed channel 10μs (50K) Turn-off delay: common channel 60μs, high speed channel 6μs (50K)
Input and internal logic circuit isolation	Photoelectric coupler 500VAC/1 min

2.2.8.3 DO(Transistor)

Input type	PNP
Rated output voltage	DC24V, allowance range: DC20.4V~DC28.8V
Output current / channel	Rated 200mA@24VDC
Inrush transient current/channel	1A, ≤1s
Output leakage current	Max: 0.5μA
Output impedance	Max: 0.2Ω
Output delay time	Turn-on delay: common channel 15μs, high-speed channel 10μs (50K) Turn-off delay: common channel 35μs, high speed channel 6μs (50K)
Protect function	Inductive load output protection short-circuit protection Output polarity reversal protection(≤10s)
Output and internal logic circuit isolation	Photoelectric coupler 500VAC/1 min

2.2.8.4 DO(Relay)

Output type	Relay
Allowable load voltage	DC 30V/AC250V
Allowable load current	2A (DC 30V/AC250V)
Output current /group	Max: 6A
Output turn-on delay time	Max: 8ms
Output turn-on delay time	Max: 5ms
Expected contact lifespan Mechanical lifespan (No load) Electrical lifespan (Rated Load)	20,000,000 times (1200 times/min) 100,000 times (6 times/min)
Isolation characteristic	Relay isolated Coil and contact isolation voltage: 2000 Vrms

2.2.8.5 AI

Signal type	4~20mA、1~5V、0~20mA、0~10V
Resolution	12 bits
Measuring accuracy	0.3% F.S.
Conversion rate (each channel)	≈200 times / s
Input impedance	Current mode: ≤250Ω Voltage mode: > 4MΩ
Anti common mode voltage	(Signal voltage + common mode voltage) ≤15V, Beyond the channel will be in the protection state.

2.2.8.6 AO

Signal type	4~20mA、1~5V、0~20mA、0~10V
Resolution (include signed bit)	12 bits
Output signal accuracy	0.3% F.S.
Conversion rate (each channel)	≈300 次/秒
External load	Current mode: ≤ 500Ω Voltage mode: ≥ 1kΩ

2.2.8.7 Communication interface

Ethernet	1 channel, support HMI configuration program up/download, connect KDManager firmware upgrade
DB9	2 channel RS485, isolation Baud rate range: 1200bps~115200bps PORT1 supports programming protocol, Modbus RTU master/slave station, and free communication 1 channel CAN, 8 KS expansion modules can be connected

2.2.8.8 Program storage and RTC

User program	Max: 4k instructions
User data	M area: 1k byte V area: 4k byte
Timer	Total: 256 1ms time base: 4 10ms time base: 16 100ms time base: 236
Counter	256
Tmer interruption	2, 0.1ms time base
Data backup	EEPROM, 448K byte
Data retention	V area: VB0-VB1907, total 1908 bytes C area: C0-C63 Lithium battery, 3 years at room temperature
RTC	When the operating environment is at 25 °C, the error is less than 5 minutes /month
Battery	Support battery voltage monitoring, can replaceable battery

2.2.8.9 Display specification

Display size	7" TFT	4.3" TFT
Resolution	800*480 pixel	480*272 pixel
Display colour	256K colour	
Brightness	250cd/m2	
Bace light	LED	
Touch screen	4-wire, precision resistance network (surface hardness 4H)	
LCD lifespan	50000 hours	
CPU	700MHz RISC	
Serial port	No	1 * RS232 (COM2) Only MK043E - 27 DT support
Ethernet	10M/100M adaptive	
Memory	128MB Flash + 64MB DDR2	
Formula memory	256K+RTC	
Extended memory	1*USB-Host	
Program download	1*USB-Slave/Ethernet/flash drive	
Printer port	USB-Host	
Software	Kinco DTools + EdgeAccess + Miot	

2.2.9 CPU power wiring diagram

2.2.9.1 DC power supply wiring diagram




Figure 2.2.9-1 power supply wiring diagram

Pin	Meaning
24V	24V DC power supply positive end
0V	24V DC power supply negative end
FG	Ground

After the module is powered on, the [PWR] indicator on the MK070E panel will always be on (green).

2.2.10 DI/O wiring diagram

2.2.10.1 Transistor type DI wiring diagram




Figure 2.2.10-1 DI wiring diagram

The CPU digital input supports NPN or PNP wiring. As shown in the figure above, when the signal flows into the 1M, it is referred to as NPN input; when the signal flows out from the (1M), it is referred to as PNP input. In the diagram, solid lines represent external wiring for PNP input, while dashed lines represent external wiring for NPN input. This wiring diagram applies to all MK series input wiring.

Pin	Meaning	Pin	Meaning
1M	24V DC + (Source type)	I0.2	Universal/high-speed input
	24V DC - (Drain type)	I0.3	Universal/high-speed input
I0.0	Universal/high-speed input	I0.4	Universal/high-speed input
I0.1	Universal/high-speed input	I0.5	Universal/high-speed input

2.2.10.2 Transistor type DO wiring diagram




Figure 2.2.10-2 Transistor type DO wiring diagram

The CPU transistor-type output only support PNP type. PNP means that when a signal is triggered, the signal outputs as high-level. in the diagram above, L- is connected to the DC 24V-, L+ is connected to the DC 24V+, and the signal is connected to the external load.

This diagram applies to all MK series transistor type output wiring except MK070E-32DX and MK070E-27DRT.

Pin	Meaning	Pin	Meaning
L-	24V DC-	Q0.2	Universal
L+	24V DC+	Q0.3	Universal
Q0.0	Universal/high-speed output	Q0.4	Universal/high-speed output
Q0.1	Universal/high-speed output	*	

2.2.10.3 Relay type DO wiring diagram




Figure 2.2.10-3 Relay type DO wiring diagram

In the diagram above, 2L is DO common terminal. Each common terminal can be connected to DC or AC power supply as needed. When the current required by the load is large, two "2L" can be connected to the power supply simultaneously to meet the requirements of the output load.

Note:

❖ The relay output-type CPU modules do not support high-speed pulse output function.

2.2.10.4 DIO wiring diagram




Figure 2.2.10-4 DIO wiring diagram

The figure above is DIO wiring diagram. Only the MK043E-27DT provides 4 channels of DIO, and each channel can be used independently as DI or DO according to the connection method. The dashed line is the NPN drain output and the solid line is the PNP source input.

Figure 2.2.10-5 shows the wiring diagram in source input mode using DIO1.5 channel as an example, and Figure 2.2.10-6 shows wiring diagram in drain output mode.




Figure 2.2.10-5 Source input (DI)




Figure 2.2.10-6 Drain output (DO)

2.2.11 AI/O wiring diagram

2.2.11.1 AI wiring diagram

MK070E-33DT and MK043E-27DT have two analog input channels (2*AI), support current input (4-20mA/0-20mA) and voltage input (1-5V/0-10V), and the measurement accuracy is 0.3% F.S. The signal form and filtering mode of the channel can be configured through KincoBuilder programming software, and each channel allows mixed access to different signals. For the configuration method, see **4.3.2 KincoBuilder configuration extension module**.

4-wire / 2-wire current input




Figure 2.2.11-1 2-wire / 4-wire current input wiring diagram

Current signal corresponding to access pin * + and R * (* indicate channel name: A/B/C/D), Taking the 2-wire current input A group as an example, signal + end of the transmitter needs to be connected to the sampling resistance "B+" of the channel, signal - end of the transmitter needs to be connected to the "A-" of the channel.

Taking the 4-wire current input B group as an example, it is necessary to connect the transmitter signal - end to channel "B-", the transmitter signal + end to RB, and the transmitter power input is connected to the external power supply.

Pin	Meaning	Pin	Meaning
RA	Channel A sampling resistance	RB	Channel B sampling resistance
A+	Channel A input signal positive	B+	Channel B input signal positive
A-	Channel A input signal negative	B-	Channel B input signal negative

Voltage input

The positive and negative terminals of the voltage transmitter are corresponding to the access pins *+ and *- (* indicates the channel name: A/B/C/D).

The MK043E-20DT has 2 analog input channels, each input channel consisting of 2 terminals, named *+ and *- (* indicates the channel name: A/B/C/D, Channel A is used as an example, the two terminals are A+ and A- and support 0-10V input voltage). For details, see **4.3.2 KincoBuilder configuration extension module**.




Figure 2.2.11-2 MK070E-33DT, MK043E-27DT voltage input wiring diagram




Figure 2.2.11-3 MK043E-20DT voltage input wiring diagram

Thermal resistance input

The MK070E-27DRT has 3 thermal resistance input channels (3*RD), each input channel consists of 3 terminals, named X1, X2, X3, (X is the channel name: A/B/C/D, take channel A as an example, the three terminals are A1, A2, A3), support Pt100 thermal resistor, 2-wire and 3-wire heating resistor. The filtering mode of each channel can be configured in KincoBuilder programming software. For the configuration method, see 4.3.2

KincoBuilder configuration extension module.

If user use 2-wire heating resistance measurement, refer to the wiring diagram of channel A in the following figure. The connection of the heating resistor does not need to distinguish between positive and negative poles, after connection, short-circuit terminals A2 and A3. If 3-wire heating resistance is used for measurement, refer to the wiring diagram of channel B in the following figure.

It is recommended that the user short-circuit the unused channel group terminals, and set the corresponding signal form of the group to [0-20mA] or [0-10V] in the programming software, artificially let the pin of this group of channels in the signal acquisition state, and release the gathered charge in the form of short-circuit to prevent false alarms caused by interference. C channel in the following figure is not in use, the three terminals of channel C can be short circuited




Figure 2.2.11-4 Thermal resistance input wiring diagram

After the input signals of each channel are sampled by ADC and linearly calculated, the calculated results are sent as measurement values through the expansion bus to the AI image area of the CPU module for user program access. Different signal types have their own measurement ranges. If the measured value exceeds the rated measurement range, the module will alarm : LED light of the channel that exceeds the range will light up (red) and

the module will automatically send a fault message to the CPU module through the expansion bus.

The following table is the measurement range and measurement value format.

I : input current value V : input voltage value.

Signal type	Measure range	Measurement value representation format
Pt100	-200~850°C	T×10 (-2000~8500)
Cu50	-50~150°C	T×10 (-500~1500)
Pt1000	-50~300°C	T×10 (-500~3000)
Resistor	0~2000Ω	R×10 (0~20000)

Thermocouple input

MK043E-20DTC has 2 thermocouple input channels (2 * TC) and supports J/K/E/T type thermocouple. It is recommended that users short-circuit the unused channel group terminals. The B channel in the figure is the unused channel, so short circuited B+ and B-. KincoBuilder can be used to configure each channel to use any type of thermocouple from J/K/E/T, measure cold end internal compensation, external compensation, and filtering methods. The configuration method can be found in **4.3.2 KincoBuilder configuration extension module**.




Figure 2.2.11-5 Thermocouple input wiring diagram

After the input signal of each channel is converted by A/D, the value obtained will be calculated and converted according to the standard thermocouple calibration table, and the result will be sent to the AI area of the CPU module through the expansion bus for user program access.

Different types of thermocouple has its corresponding measuring range, if the measured value is beyond the rated range, the module will alarm. The following table shows the measurement range and measurement value format (T: measured temperature value) .

Note:

- ❖ Since the cold end temperature measuring element is installed inside the module, when using the internal compensation method, the measurement results will be affected by the heating generated by the module during operation. Normally, the measured value of the internal compensation method is about 2° C ~ 4 ° C higher than the actual temperature.

Thermocouple type	Measure range	Measurement value representation format
J	-100~1200°C	T×10 (-1000~12000)
K	-100~1300°C	T×10 (-1000~13000)
E	-80~1000°C	T×10 (-800~10000)

T	-100~400°C	T×10 (-1000~4000)
---	------------	-------------------

2.2.11.2 AO wiring diagram

Current/Voltage output

The MK070E-33DT and MK043E-27DT have 1 current/voltage output channel, and each channel consists of I, V, and M. For the configuration method, see **4.3.2 KincoBuilder configuration extension module**.




Figure 2.2.11-6 AO output wiring diagram

The analog output channels in the figure above support both current and voltage output modes. I, V, and M correspond to the current output, voltage output, and common terminal respectively. Current type output correspond to pin M and pin I, and voltage type output correspond to pin M and pin V.

When wiring, connect the analog output positive terminal (+) to the external device analog input positive terminal, and connect the analog output negative terminal to the external device analog output negative terminal.

2.2.11.3 Analog measurement range and measurement value representation format

After the input signals of each channel are sampled by ADC and linearly calculated, the calculated results are sent as measurement values through the expansion bus to the AI image area of the CPU module for user program access. Different signal types have their own measurement ranges. If the measured value exceeds the rated measurement range, the module will alarm.

It is recommended that the user short-circuit the unused channel group terminals, and set the corresponding signal form of the group to [0-20mA] or [0-10V] in the programming software, artificially let the pin of this group of channels in the signal acquisition state, and release the gathered charge in the form of short-circuit to prevent false alarms caused by interference.

The following table is the measurement range and measurement value format.

I : input current value V : input voltage value.

Thermocouple type	Measure range	Measurement value representation format
4~20mA	3.92~20.4mA	I×1000 (3920~20400)
0~20mA	0~20.4mA	I×1000 (0~20400)
1~5V	0.96~5.1V	V×1000 (960~5100)
0~10V	0~10.2V	V×1000 (0~10200)

The AQ output value specified in the user program is first sent to the corresponding AO module through the expansion bus, and then calculated, transformed, and output to the specified channel through DAC. The output of different signal form have its rated range. If the specified output value in the user program exceeds the upper and


lower limits of the selected range, the corresponding values of the upper and lower limits will be output.

The following table is the output range and output value representation format.


I : actual current value V : actual voltage value.

Signal type	Output range	Output value specified in the user program
4~20mA	3.92~20.4mA	$I \times 1000$ (3920~20400)
0~20mA	0~20.4mA	$I \times 1000$ (0~20400)
1~5V	0.96~5.1V	$V \times 1000$ (960~5100)
0~10V	0~10.2V	$V \times 1000$ (0~10200)

2.2.12 MK series product wiring summary




RS485/CAN
(in DB9)



Definition	Describe	Pin
Port1	A	6
	B	1
Port2	A	9
	B	4
CAN	CANH	7
	CANL	2
GND	GND	5

Figure 2.2.12-1 MK043E-20DTC wiring diagram



RS485/CAN
(in DB9)



Definition	Describe	Pin
Port1	A	6
	B	1
Port2	A	9
	B	4
CAN	CANH	7
	CANL	2
GND	GND	5


Figure 2.2.12-2 MK043E-20DT wiring diagram

In all series, each DIO channel can be connected to the circuit via DI (NPN) input or DO (PNP) output.

DIO Wiring Method:

Real lines is the DI input wiring method;

Dashed lines is the DO output wiring method



RS232/RS485/CAN
(in DB9)

Definition	Describe	Pin
Port1	A	6
	B	1
Port2	A	9
	B	4
CAN	CANH	7
	CANL	2
COM2	RX	3
	TX	8
	GND	5




Figure 2.2.12-3 MK043E-27DT wiring diagram





Figure 2.2.12-4 MK070E-27DRT wiring diagram





Figure 2.2.12-5 MK070E-32DX wiring diagram




Figure 2.2.12-6 MK070E-33DT wiring diagram




Figure 2.2.12-7 MK070C-33DT wiring diagram




Figure 2.2.12-8 MK043C-20DT wiring diagram

2.2.13 MK series product dimension




Figure 2.2.13-1 MK070E-33DT/32DX/27DRT,MK070C-33DT dimension




Figure 2.2.13-2 MK043E-20DT/20DTC, MK043C-20DT dimension




Figure 2.2.13-3 MK043E-27DT dimension

3 Installation guideline

3.1 MK series product connect expansion module

The standard MK series product support up to 8 KS expansion modules. CAN communication protocol is used between the MK and the expansion module. However, the CAN communication physical interface and two RS485 communication physical interfaces of the MK are placed in the DB9 connector. The physical CAN communication interface of the KS expansion module is an RJ45 connector. Therefore, if the MK wants to connect the first KS expansion module, user need to prepare a DB9-RJ45 communication cable.

The pin definition and connection relationship of CAN communication protocol in different connectors are shown in the following table.

MK : DB9 connector	KS expansion module : RJ45	Definition
PIN7	PIN 1	CAN_H
PIN2	PIN 2	CAN_L
PIN5	PIN 3	CAN_GND

At the top of the KS expansion module, there are two RJ45 interfaces, EXT. OUT and EXT.IN, which can be distinguished by the information stickers on the front of the module. Connect the RJ45 interface of the DB9-RJ45 cable to the EXT. IN of the first expansion module. Connect EXT.OUT of the first expansion module to EXT.IN of the second expansion module using a network cable, repeat this process to connect the expansion modules. Taking the example of connecting the first expansion module KS133-06IV to the second expansion module KS131-04RD in the following figure



Figure 3.1-1 KS connection method of the expansion module

After the hardware connection is correct, you need to configure the KincoBuilder software to use the module function. For details, see **4.3.2 KincoBuilder configuration extension module**.

Note:

- ❖ Before connecting the expansion module, confirm EXT.IN and EXT.OUT., which can be used when the connection is correct.
- ❖ Please ensure that the expansion cable is securely plugged in, otherwise it may cause poor contact and system communication failure.

3.2 Dis/Assembly of terminal blocks

3.2.1 Disassembly of terminal blocks

Hold the protruding parts on both sides of the top of the terminal block, and apply vertical force to pull out the terminal block.




Figure 3.2.1-1 MK terminal block




Figure 3.2.1-2 MK terminal block disassembly operation diagram

3.2.2 Assembly of terminal blocks

1.Align the protruding positioning teeth at the tail of the terminal block with the terminal slot



Figure 3.2.2-1 Terminal block assembly diagram1

2.Press down firmly into the terminal block until it fits into the terminal slot



Figure 3.2.2-2 Terminal block assembly diagram2

3.3 Installation method

The packaging box of the MK series product contains a sealed pocket with fixed accessories, which contains 4 installation buckles and screws. The MK070E has square mounting slots on the upper, lower, left and right sides. In the KincoDTools software, MK supports editing the configuration screen in a vertical or horizontal posture. Users can choose to install the installation buckles on the top and bottom sides or left and right sides according to their needs.




Figure 3.3-1 MK043E packaging box-fixed accessory




Figure 3.3-2 MK070E packaging box-fixed accessory



Figure 3.3-3 MK installation buckles



Figure 3.3-4 Install the fixed accessories on the upper and lower sides



Figure 3.3-5 Install the fixed accessories on the left and right sides

The installation steps are as follows:

- ❖ Place the MK into the installation holes on the device control panel, and clamp the installation buckle hook into the square installation slots on the upper and lower sides or left and right sides as needed.
- ❖ Tighten the screw clockwise with a recommended torque of $0.5\text{N}\cdot\text{m}$ to achieve waterproof and dust-proof effect and avoid shell deformation.




Figure 3.3-6 Fixed accessories installation diagram

4 Getting started with Kinco Builder

KincoBuilder is a programming software for Kinco K-series PLC, compliant with the IEC61131-3 standard, enabling users to carry out efficient program development. Here is a brief getting started guide to assist users in quickly getting acquainted with KincoBuilder.

4.1 Software interface introduction





Figure 4.1-1 KincoBuilder interface overview

Num.	Item	Description
①	Menu bar	The Project menu contains all the operational commands of the KincoBuilder.
②	Toolbar	The Toolbar contains some frequently used operational commands.
③	Variable definition area	For variables declaration
④	Programming area	For program editing, the LD editor or IL editor can be chosen optional
⑤	Project management area	The Project manager is one of the main windows in the interface, which intuitively links all components of the current project in a tree structure, including programs, hardware (configurations), status chart, global variable (tables), etc. Users can manage, operate, and maintain the current open project in this device tree. Each node in the project manager supports right-click operations to pop up corresponding windows.
⑥	Output	Information window, is used to display various prompts of the KincoBuilder. The "Compile" window shows the compilation information of the user's last compilation. The "general information" window displays a information of some recent actions.
⑦	Status Display Bar	The status bar is used to display the current status of the software and prompts for operational commands.

KincoBuilder has organized some commonly used functions into sections on the toolbar for user convenience. Hovering the mouse pointer over the corresponding icons allows to view brief descriptions of the functions and their corresponding shortcut key operations. For more detailed information, please refer to the relevant application manual.

4.2 Create a New Project

There are two ways to create a new project in KincoBuilder. First, double-click the KincoBuilder icon  to open the software. The following image shows the initial interface after opening the software.




Figure 4.2-1 KincoBuilder initial interface

User can create a new project by selecting [New Project...] under the [File] menu in the menu bar. Alternatively, you can quickly create a new project by clicking the [Create a new project] on the toolbar.




Figure 4.2-2 New project path

In the pop-up [New Project...] dialog box, select the location to save the project, modify the project name and then click "Save" to complete the creation.

4.3 Hardware configuration

4.3.1 Configure the CPU

After a new project is created, the program will set the CPU to K606-24DT by default. The user needs to modify the CPU according to the actual hardware model. The default configuration model of the new project can also be opened by [Tools]→[Options] on the menu bar. Select the desired CPU model from the Default CPU model drop-down list under **Default Project Properties** and click **Apply** to save the settings.

Here's an example for how to configure the MK070E-33DT. In KincoBuilder, User can find [Hardware] in the left device tree and double-click to open it. User can also click the "**Open hardware configuration**" button on the menu bar to open the hardware configuration interface.




Figure 4.3.1-1 Hardware configuration interface

After opening the [Hardware] interface, the first row displayed in the hardware configuration list is indeed the currently configured CPU. When changing the configuration, you need to delete the module configured (Right-clicking on the module name to delete the configured module). Then, in the [HW Catalog], find the MK070E-33DT, and double-click to automatically add it to the project.




Figure 4.3.1-2 Delete module




Figure 4.3.1-3 Configure MK070E-33DT

I/O , Comm,Reten, CANop , and more can be performed on the Hardware interface. For more detailed configuration tutorials, please refer to the software user manual.




Figure 4.3.1-4 MK070E-33DT configuration interface

4.3.2 Configure the expansion module

After the correct connection of the expansion module , its expansion function needs to be configured through KincoBuilder software before it can be really used. The specific steps to enable the expansion module on the software are as follows: [Hardware]→[HW catalog]→[KS/KW]→[Digital module]/[Analog module], select the expansion module and double-click to add it.




Figure 4.3.2-1 Add expansion module

If you need to set the expansion module, click the corresponding module model to open the related setting interface.




Figure 4.3.2-2 Expansion module configuration

Note:

- ❖ In KincoBuilder, the configuration order of expansion modules must match the actual hardware connection sequence. Otherwise, it may cause errors in the PLC.

4.4 Programming simplified guide

4.4.1 On-line Help

In KincoBuilder software built-in more detailed instructions, the user can click on the toolbar [Help] → [Contents and Index] to open the online-help interface to find programming instructions quickly.




Figure 4.4.1-1 Help interface

In the left navigation bar, it supports finding detailed instructions through browsing the directory, keyword indexing, and searching. It also supports adding the found information to the favorites folder.




Figure 4.4.1-2 KincoBuilder help interface

4.4.2 Programming language

KincoBuilder supports programming using IL (Instruction List) language and LD (Ladder Diagram) language. You can switch between these languages in the software by accessing the toolbar and selecting [Project].




Figure 4.4.2-1 KincoBuilder help interface

4.4.3 Programming instructions

This section does not introduce the specific usage of programming instructions. It only explains how to quickly obtain help and instructions for programming instructions:

1. After selecting a specific instruction in the edited program, press the F1 shortcut key, then will automatically open the online help and navigate to the corresponding instruction's explanation.




Figure 4.4.3-1 MOVE instruction description interface




Figure 4.4.3-2 User manual

2.To find the usage of the corresponding instructions through the software manual. Please download the software user manual from the official Steps website. Product version iterations may lead to some lag in both the software and its user manual. Please ensure to download the latest version of the software and the corresponding user manual from the official website promptly. (<https://en.kinco.cn/download/plc87.html>)

4.5 Compiler and Simulator

4.5.1 Compiler

The PLC compiler will verify all instructions supported by the actual PLC and the structure of user programs. All errors in the KincoBuilder compiler will be listed in the [Output] window. Double-clicking on error messages listed in the [Output] window will automatically locate the error.

The program can be compiled by clicking [Project] → [Compile All] on the toolbar, or by using the [F7] shortcut key. After successful compilation, the number of generated instructions will be displayed.




Figure 4.5.1-1 Compile path

4.5.2 Simulator

In KincoBuilder, an offline simulator for KPLC is provided, supporting simulation of actual program execution and debugging of user programs while offline. The simulator offers practical debugging features such as breakpoints, single-step execution, single-network execution, pause/resume operation, and serial communication simulation.




Figure 4.5.2-1 Start simulator

Run continuously:After the simulator is started, it performs cyclic scanning and execution of the program.

Pause at the first network:After the simulator is started, it stops executing after completing the first scan cycle.




Figure 4.5.2-2 Simulator interface

NO.	Item	Description	
①	Toggle monitoring mode		Click to enter or exit monitoring mode
②	Enter/Exit simulation mode		Click to enter offline simulation mode.
			Click to exit offline simulation mode.
③	Function shortcuts for offline debugging		Restart the simulation.
			Stop the program execution.
			Continual the program execution
			Adjust the scan cycle of simulation
			Execute an instruction
			Execute a network
			Execute to the network where cursor(line)
			Add/remove the breakpoint
			Disable/enable the breakpoint
			Disable all breakpoint
			Enable all breakpoint
④	Debug program	The [Debug program] window includes features such as: ❖Current status display ❖Execution of scan cycles(executed) ❖Program network display(current) ❖Jump to the next network ❖Execute the specified scan cycles	
⑤	I/O channels	Input or output signals can be simulated by checking the corresponding IO channel option.	
⑥	Communication simulator	Suitable for simple communication simulation debugging of XMT RCV commands	
⑦	Programming Area	This area allows the user to observe the program running and debug the program manually	

4.6 Connection and program up/download

4.6.1 MK series PLC communicate with PC via USB-Slave

User need to use a USB-B programming cable to connect the PC and MK . The DB9 port on the back of the MK has two RS485 ports, and only Port1 supports the programming protocol and power on the PLC.

In this example, the serial port number being used is COM3. Select **[Use COM Port]** in Communications and modify the **[Port]** to match the actual port number. (please confirm the actual COM port through the PC's Device Manager)




Figure 4.6.1-1 COM port setting

Click on **[Start]** to scan for device. After successful recognition, the **[Local Parameters]** in KincoBuilder will automatically correspond to the actual parameters. Finally, click "OK" to complete the connection.




Figure 4.6.1-2 COM port scan

4.6.2 Program upload/download

KincoBuilder provides two ways to upload the program: [**Upload**] and [**Upload (breakpoint resume)...**]. Breakpoint transfer refers to the ability to resume transmission from the point where it was interrupted or failed during the file transfer process. This way allows file transfers to be completed efficiently even if the network is unstable or the transfer process is interrupted. Therefore, in situations where the network is busy, long-distance transmission, or for large project sizes, it is recommended to use [**Upload breakpoint resume)...**] for program uploading. On the contrary, [**Upload**] is a one-time transfer, if any error or interruption occurs during the program transfer, KincoBuilder will interrupt the uploading process directly and return an error, requiring the user to re-trigger the upload operation and start the transfer from the beginning




Figure 4.6.2-1 Program upload trigger path

The process for program uploading is as follows: Before initiating the upload operation, please ensure that communication between the PC and PLC is functioning properly. Open the upload window by [**PLC**] → [**Upload**] or [**Upload(breakpoint resume)...**] from the menu bar. Once the upload is complete, a window for selecting the save path will pop-up. Choose the target save path and click OK. After the upload is finished, the uploaded project will automatically open.




Figure 4.6.2-2 Program upload process

KincoBuilder offers two methods of program downloading: [Download] and [Download (breakpoint resume)...]. Similarly(refer to Program Upload), when the program download process is frequently interrupted, the network is busy, long-distance transmission is required, or for large project sizes, it is recommended to use [Download (breakpoint resume)...] for downloading programs.




Figure 4.6.2-3 Program download trigger path

The process for program downloading is as follows: Before initiating the download operation, please ensure that communication between the PC and PLC is functioning properly. Open the download window by selecting [PLC] → [Download] from the menu bar or by using the shortcut key [F8]. Prior to the start of the download process, KincoBuilder will automatically compile the current project, and relevant information will be displayed in the [Compile] window. After successful compiling, clicking [Download], then will trigger the download process normally. Upon completion of the download, there will be a prompt in the [Output] window, displaying information such as the software version and model of the current device.




Figure 4.6.2-4 Output window

MK series integrated(PLC+HMI) user manual

Option	Description
Set the CPU to “Upload Disabled”	Enabling this option will encrypt and store all user programs in the PLC, and "Upload program" will not be supported. Please be careful when enabling this option and take care of program backup
Clear the Retentive Ranges in V area after downloading	Enabling this option will clear all data in the V-area and C-area of the Data Maintain after program downloading, while disabling it will have no effect.
Clear the Permanent Backup Ranges after downloading	Enabling this option will clear all data in the Permanent Storage after program downloading, while disabling it will have no effect
Not automatically compiled before downloading or monitoring(not recommend)	Enabling this option will prevent automatic compilation after clicking "Download" or "Toggles Monitoring Mode(F6)" in this session, which may lead to abnormal program execution or monitoring. This may not be conducive to program troubleshooting and monitoring. Please be careful when enabling this option. This setting is only valid for the current session and needs to be re-enabled after restarting KincoBuilder.

4.7 Error message and solution

4.7.1 Error Message in KincoBulider

Before viewing the PLC error message, please make sure that the PLC and PC are communicating normally, otherwise, please refer to "[Conneted to PC](#)" for connection




Figure 4.7.1-1 PLC error message query path

4.7.2 Common Error

The error message consists of an error code and a description of the message. The following are common error codes encountered by users during initial use, along with their corresponding solutions.

Error code	Description	Solution
20	The PLC in "Hardware" does not match the actual connected CPU.	This error is generally due to a mismatch between the PLC being used and the PLC configured in KincoBuilder. Please check and correct the settings in the "Hardware" section
21	There are errors in the "Hardware" configuration for the expansion modules.	First check whether the order of adding modules in [Hardware] is consistent with the actual connection order, and then check whether the added modules match the actual modules.
29	Unknown instructions are detected in the PLC program during power-on.	This error usually due to the firmware version does not match the programming version. When KincoBuilder updates, it may modify certain instructions, and new instructions and features require compatible software and firmware. Please check the current KincoBuilder and firmware versions. New software can be obtained from the official Kinco website, while PLC firmware can be obtained by contacting Kinco's technical support or local service centers.

If you need more detailed explanations of error codes, please open the Online Help or download the "Kinco-K Series Application Manual" from the official website.

4.8 Firmware update

KincoBuilder comes with a firmware update program, users can connect the PLC through the KincoBuilder to update the firmware of the PLC: [Tools] → [PLC Firmware Upgrade(Common)...].




Figure 4.8-1 PLC Firmware Upgrade

Open the firmware update program will pop up the update operation prompt page, as shown in the following figure:




Figure 4.8-2 Program update interface

The method of entering the system update mode varies depending on the PLC product.

Before starting the firmware update, read the **[Help]** instructions on the **[Upgrade Firmware for Kinco KPLC]** carefully. The specific update procedures are listed on the left side of the pop-up window. Please follow the instructions according to your model.





Figure 4.8-3 Help document description

The steps for updating the firmware of MK series PLC using the USB-Slave are as follows:

1. Use the USB-B cable to connect the PLC to the PC via USB port and power up the PLC.
2. Click on **[Communiations...]** to configure the communication parameters.



*Taking COM6 as an example, the actual selection of the COM port needs to be based on the COM port displayed in the device manager of the computer control panel.

*The station address must be 1.

3. Click on [Select Firmware File...] and choose the target file and then click "OK".

ps: If the selected file is valid, the "File Information" section will display the applicable PLC mode, hardware version, and firmware version.

4. Click on the [Enter Upgrade Mode]. After about 2 seconds, the "Run" light on the PLC panel will flash rapidly, indicating that the PLC has successfully entered system update mode.

5. Click on the [Start Upgrading] to initiate the system update for the PLC. The update process includes erasing the PLC's FLASH data, writing new data, and verifying the written data.

The "Operation Information Prompt" at the bottom of the window will display the ongoing operations and progress. If there are any errors, they will be listed along with the error reasons.

6. After receiving a successful update prompt, restart the PLC to ensure it automatically loads and runs the new firmware program.

Solution for Firmware Update Failure:

If encounter an error message indicating a failed update during the process, and the PLC [Run] light is continuously flashing, then try repeatedly clicking on [Start Upgrading]. If, after restarting the PLC following a failed update, the PLC can be connected but cannot enter the update mode, try power off the PLC for a while before update again.


If firmware update still cannot be performed, please check the [Run] light, battery level, and firmware version, and then contact Kinco Technology Support or local agents for assistance

5 Getting started with KincoDTools

KincoDTools configuration editing software is a special human-machine interface configuration editing software developed by Kinco for Green series and Future HMI.

The software installation process and configuration requirements are omitted here. This document only provides brief operations to get you started. For details about how to use KincoDTools, see **5.4.2 KincoDTools User Manual**.

5.1 KincoDTools create new project

There are two ways to create a project in KincoDTools. First, double-click the KincoBuilder icon  to open the software. The following picture shows the initial interface after opening the software:




Figure 5.1-1 KincoDTools initial interface

5.1.1 Initial interface function description




Figure 5.1-2 KincoDTools interface description

Num.	Project	Description
①	Menu bar	The menu contains all the operation commands of KincoDTools software.
②	Tool bar	The Toolbar contains some frequently used operational commands.
③	Status display	The status bar provides the current software status information and prompts for toolbar operation commands.
④	Component library window	There are three device pages: Connector, HMI, and PLC. Hold down the desired device and drag it to the device topology window to add the device. Click to view the device information. Connector page: Contains commonly used communication connection cable HMI page: Contains all HMI models of Kinco PLC page: Support other manufacturers PLC equipment except Kinco Details of the relevant connection settings can be found in [Communication Connection Help (C)] in the menu bar [Help (H)].
⑤	Device topology window	Display the topology connection screen of the added devices.
⑥	Project structure window	There are two information pages for project tree and address browsing. Project tree: After the project is successfully created, the library file, HMI, PLC information of the project file is displayed. Address browsing: It can display the address usage of HMI and PLC register and the use location, name and corresponding data in the project.
⑦	Compile information window	Displays project status and compilation information.
⑧	Mouse coordinate display	Assist users to set X and Y axis parameters when using window elements.

User can create a new project by selecting [File]→[New (N)]. Alternatively, you can also create a new project

by directly clicking the [New Project] button on the toolbar




Figure 5.1-3 Create new file

Then in the pop-up [New project] dialog box set the project name, select the project save location, HMI series and HMI model, here to create a project name of "Test_1" MK070E project as an example.




Figure 5.1-4 New project dialog box




Figure 5.1-5 Set the project name “Test_1”




Figure 5.1-6 Change the project path

In the KincoDTools software, the MKseries can edit the configuration screen in a vertical or horizontal attitude. User can select horizontal or vertical in the **Display mode**. If this parameter is incorrect, you can modify it after the project is created. For details, see **5.2.1 Add/Delete HMI**




Figure 5.1-7 Display mode




Figure 5.1-8 Set HMI model

After setting, click [Next >>] to complete the project creation.

5.2 KincoDTools system parameters set

After the project is created, the system parameters set page is displayed. On the page, you can change the HMI type, set the network IP address, and add network port or serial port device parameter setting.




Figure 5.2-1 System parameter setting interface

5.2.1 Add/Delete HMI

If the user selects the wrong HMI model and display mode in the [New Project] step, they can add the correct HMI model in the [System Parameter Set] interface.

The operation steps are as follows: select the device [NO.] → click [Delete] → Select [Y] in the pop-up prompt box → Click the [▼] button in the column of HMI Type → Select the correct model in the HMI model list → Select the display mode in the same way if necessary → click [Add], users can add multiple HMI devices. Taking the replacement of MK070E with MK043E as an example.




Figure 5.2-2 Modify HMI model

5.2.2 Network device and serial port setting

Network device setting

User need to set the IP address of the HMI through the network configuration, so that the PC can download the HMI configuration program and other network port communication devices can connect to the HMI. The network IP address can be set in the [System Parameter Set] interface. Click [Network Device Setting] → Click [Add] in the pop-up window. In the new pop-up window, there are three parameters that can be modified: Device NO. , IP Address, and Comm Protocol.

- **Device NO. :** HMI0 corresponds to the HMI with serial number 0. If the user has added multiple HMI devices, they can switch to the corresponding devices for settings;
- **IP Address:** The modification here is the IP address of the HMI device which selected for the Device NO.
- **Comm Protocol:** The default is Kinco communication protocol. If users need to connect other devices, they can select the protocol of the corresponding manufacturer from the list called by the [▼]




Figure 5.2-3 Network device setting

Select the default Kinco communication protocol here, set the IP address of the corresponding device, and click [OK]. In the figure, change IP address to 192.168.0.150 as an example, click [OK], then check the IP address and communication protocol corresponding to the HMI device number, and click [OK] again. The IP address of HMI network port 0 is successfully changed to 192.168.0.150.




Figure 5.2-4 IP address setting

Serial port setting

Serial port 0 parameter setting is an important action to connect the MK series PLC and HMI . Click [COM0], select the manufacturer [Kinco], select the communication protocol [Kinco PLC Series], click [Add] after selecting, and finally select [Finish]. You can observe that the device topology on the engineering page has changed.




Figure 5.2-5 COM0 setting




Figure 5.2-6 Finish COM0 setting




Figure 5.2-7 Device topology window

5.3 Startup menu

Hold pressing on the touch panel when you power on HMI, then HMI will enter operation mode selection window, select the operation mode according to your application. The following function buttons are displayed on the startup menu:

System setup: Press this button to enter system setup window. This window is used to set the startup animation, screen saver time, buzzer sound, brightness adjustment, system time, initial window, and IP address .After setting, press Restart button to restart HMI.

Firmware Update: Press this button to enter firmware update mode. This window is used to update firmware.

Normally this mode is not advised to use without guiding by manufacturer.

Touch calibration: If the screen touch is not accurate after updating the firmware version, the user can calibrate the HMI screen in this mode

Stop timer: After entering the operation mode selection screen, the countdown clock starts automatically. If no operation is performed within 20 seconds of entering the operation mode selection screen, the system automatically restarts and enters the engineering screen. If you are worried that the 20s event is too short to operate, you can click this button to stop the countdown and keep the MK in the startup menu interface.

5.4 Configuration Editor

5.4.1 Configuration editor window

The device topology window shows the communication connection of the MK. If you want to draw the configuration interface to control the connected device, you need to enter the configuration editing window. The operation steps are as follows: click the menu bar [**Window (W)**], and click the drop-down menu bar [**HMI Edit Window (E)**].




Figure 5.4-1 Enter HMI Edit window

After successfully entering the HMI Edit window, you will see the following interface:




Figure 5.4-2 HMI Edit interface

Num.	Project	Description
①	Toolbar	The Toolbar contains some frequently used operational commands.
②	Graph element window	There are three pages of PLC Parts, Functional Parts and Project database. PLC Parts: This page is mainly for control and display components, write/read address can be set to HMI or PLC address; Functional Parts: This page is for specific functional components; Project database: This page component is used by double-clicking to store engineering data information
③	HMI configuration window	The white part with a dot matrix is the displayable part of the MK. All configuration components can only be drawn in this area. The user can adjust the size of this area by Ctrl+ mouse wheel.
④	Project structure window	There are two information pages for Project Tree View and Address browsing. Project Tree View : After the project is successfully created, the library file, HMI, PLC information of the project file is displayed. Address browsing: It can display the address usage of HMI and PLC register and the use location, name and corresponding data in the project.

5.4.2 KincoDTools user manual

This manual is only a brief introduction. If user need to know the usage of a specific component or function, click on the menu bar [Help (H)], find [User Manual (M)], and click to open the KincoDTools user manual




Figure 5.4-3 Open user manual

5.4.3 Add component

KincoDTools has two ways to add components:

- (1) Click [**Components(I)**] on the menu bar, hover the mouse over the component category to find the desired component, and click Add;
- (2) Find the desired component in the Graph element window, press the icon with the mouse and drag it to the HMI configuration window to complete the addition.

Components in the Project database page can be added by double-clicking the component icon, or clicking [**Lib (L)**] in the menu bar, and then clicking the desired library. For details, see **5.4.2 KincoDTools user manual**

Take the Bit State Switch of adding PLC parts page as an example.




Figure 5.4-4 Add component method




Figure 5.4-5 Add library method

After adding the component, a component property setting window will pop up. There are multiple subpages in the component property setting window for setting. We take the example of creating a startup button with address M0.0.

Basic Attributes: Set the object and address type related properties for component operations

Bit State Switch : Set the Switch Type, execution mode, and output mode.

Tag: Set the tag content displayed for each state of the component

Graphics: Set button in different states to display graphics, support import images

Control Setting: Set the operating conditions and operating time of the component, and set the function of trigger macro execution or trigger register

Display Setting: Set the display condition of the component and the size and position of the component




Figure 5.4-6 Set element adress type




Figure 5.4-7 Set Switch type and Tag




Figure 5.4-8 Set Graphics

After the setting is complete, click [OK] to complete the button creation. If you want to modify the setting after the component is created, you can double-click the created component to call the properties setting window.



Figure 5.4-9 Successfully created bit state switch

5.4.4 Add frame

KincoDTools allows to create up to 32768 frame, which are numbered from 0 to 32767 and displayed as [Window number: Window name] in the project tree view. Users can click the menu bar [Screen (P)], click [Add Frame (N)], set the window information in the new window property page to add.




Figure 5.4-10 Frame Position information

The created [10:CW] can be seen in the project tree view. Click and jump to this window for configuration screen editing.




Figure 5.4-11 Add new frame successfully

5.5 Macro

5.5.1 Create macro file

If the components provided by the component window attribute cannot meet the specific needs of users, it can be realized by creating macro code in C language. Click [**Macromode... (M)**] in the menu bar [**Lib (L)**], set the macro file name and corresponding group number to create macro file. Macro files are divided into three groups 0-2 in the project tree view for management, which is convenient for user to distinguish macro files of different control devices.




Figure 5.5-1 Create macro file




Figure 5.5-2 Micro interface

5.5.2 Add variable

Click the right mouse button in the [Parameters] window, click [Add Variable], set the variable name, data type, variable address and R/W properties, click [OK] to create a variable.




Figure 5.5-3 Create variable

Data Type	Param name	PLC No.	PLC Address type	Address	WordNum	OptMode	Array	Array Length	Address Label
bit	Start	0	M	0.0	1	Read/Write	No		

Figure 5.5-4 Add variable successfully

5.5.3 Macro file compilation and use

After the macro file is written, it must be compiled and the compiled result is correct before it can be used. User can click the right mouse button in the [Macro operation window] or in the [Parameters] to find [Compile Macro], click to compile.

The compilation result can be viewed in the Message window.




Figure 5.5-5 Add variable successfully

Users can choose to use **timer** or **function key** buttons to execute macro code, and can find them on the **[Function Parts]** page in the **[Graph element window]**. The difference between the two is that the timer element is triggered without button, and the macro code is executed when the execution conditions are met. The triggering mode, execution period, response mode, and repetition times can be set, and the timer element can be placed in the conditional triggering window or the public window(public window is always displayed on other window. For details, see **5.4.4 Add frame**). The function key element is triggered by the button and executes the corresponding macro file by pressing the button.




Figure 5.5-6 Set Timer




Figure 5.5-7 Set Function key

5.6 Offline Simulation

After completing the editing of the engineering configuration, it needs to be compiled before it can be downloaded and simulated. "Offline Simulation" function can simulate the effect of the engineering configuration running and without connecting to the MK, eliminating download the engineering to the MK for verification every time changes are made, greatly improving programming efficiency.

In the menu bar [Tools (T)], you can find [Compile All (R)] and [Offline Simulation (F)]. The current version directly selects offline simulation to automatically compile, but it is still recommended that users develop the habit of compiling the project before offline simulation. Select the HMI to be simulated in the pop-up dialog box, and then click [Simulate] to enter the offline simulation running screen. Click the button in the screen to view the operation effect of the project.

The remaining two simulation methods need to be performed with a connected MK, and users can choose according to their needs.

Indirect Online Simulation: User need to connect the PLC and HMI, you can get dynamic PLC data, the operating environment is the same as after downloading, there is no need to repeatedly download the project to the HMI

Direct Online Simulation: User need to connect the PLC, you can get dynamic PLC data. In the absence of HMI, it can be used to check whether the communication is normal.




Figure 5.6-1 Creat simulation




Figure 5.6-2 Simulation button




Figure 5.6-3 Offline simulation operation effect

5.7 Special register function

HMI provides special registers to complete specific functions, tick [System Register] on the component attribute page, then click [▼] at the end of the address type , open the address detailed Info page to view, select and

search the special register address function, double-click to use the required special register, and click [OK] to complete the creation.

For complete system register addresses and functions, refer to section 18.2 HMI System Special Registers in the **KincoDTools User Manual**.




Figure 5.7-1 Set the system register

5.8 IOT function

MK series supports the IOT function, users can see the current supported IOT implementation method in the menu bar [IOT (I)]. For detail , see **KincoDTools user manual** Chapter 17 .




Figure 5.8-1 IOT function

5.9 Project download

5.9.1 Compile & Download

If the offline simulation results of the project are correct, the project can be downloaded to the MK . Before downloading, the project also needs to be compiled and the compilation results are correct. Click [Tools (T)],

[**Compile All (R)**] on the menu bar, the Message window displays the editing result is complete, click [**Download (D)**], in the pop-up download setting dialog box to confirm whether the current communication mode is correct, user can click [**Set**] to modify the communication mode. Select the required options in the column of [**Select Section**], and finally click [**Download**] to complete the download operation.




Figure 5.9-1 Compile location




Figure 5.9-2 Building project

Message window

```
Compile macro_0...
Connecting...
Compilation Done! Warning 0 Error 0!
```

Figure 5.9-3 Compiler result




Figure 5.9-4 Communication Set




Figure 5.9-5 Select Section

Name	Description
Data file	Download project files in .pkg , .pkgx format
Recipe file	Download recipe files in .rep fommat
Logo file	Download Initial Start Window in *.bmp/*.jpg/*.gif/*.logo format
Clear recipe	Clear recipe data saved in RB/RBI/RW/RWI

MK series integrated(PLC+HMI) user manual

Clear history event data	Clear the record in [Event Display] / [Historical Event Display] parts
Clear history record data	Clear the record in [Historical Event Display] / [Trend Curve] / [Tend Curve] parts
Clear data report	Clear data saved in 【Data Report】 parts
Clear ERW data	Clear the data saved in external register ERW/ERWI
Clear FRW data	Clear the data saved in FLASH register FRB/FRBI/FRW/FRWI
Download to USB 1	Download the prject files to external register USB1
Download to USB 2	Download the prject files to external register USB2
Download to SD	Download the prject files to external register SD
Resume To Default Setting	Recovered the data above LW10000, Default check
PC synchronization time	Synchronize PC time to the MK
Update IP after download	Update the current network Port and port number of the HMI to the configured IP address and port
Timeout	Set the timeout time of download, the unit is millisecond, and it ranges from 0 to 65535

5.9.2 Flash drive download PLC program

MK supports the USB-host connection USB flash drive (must be FAT32 format USB flash drive) to update the PLC program function. User need to download **KincoDTools V4.3.0.2** or later to update the firmware. If the MK is delivered, consult the technical department to obtain the software patch package to update the firmware. (Note: After the patch is replaced, the functions are downloaded and updated along with the HMI project. Please recompile the HMI project and download it, otherwise the patch will not take effect).

USB flash drive download PLC program operation steps are as follows:

Power on the device by long pressing the screen with two fingers, the device will enter the setting background, enter the [System Settings] interface, click the [File Manager] page and click [PLC Project Download], the following three project download options will pop up:




Figure 5.9-6 Download interface

MK series integrated(PLC+HMI) user manual

Project	Description
The currently downloaded user project is prohibited from uploading	After this option is checked, all user programs stored by the PLC will be encrypted and stored in ciphertext, and the "upload" operation is not supported. Please check with caution and pay attention to program backup.
Clear permanent data backup area after downloading	After this option is checked, all data in the permanent data backup area will be cleared after this download. If not, the data in the permanent data backup area will remain unchanged after this download.
Clear the data hold area in V zone after downloading	After this option is checked, all data in data retention area V and C will be cleared after this download, otherwise, data in data retention area V and C will remain unchanged after this download.

After click **[OK]**, you will enter the USB flash drive and select the required PLC project file (default.obj format). The.obj format file is automatically generated after the project is compiled. If there is no such format file in the folder of the USB flash drive, the user needs to reopen the KincoBuilder project file for automatic generation after compilation.

Select the program and click**[OK]** to update the program. If the PLC has been encrypted, a password box will pop up for verification when downloading, enter the password and click OK to download normally. The device will restart automatically after the USB flash drive transfers the PLC program successfully.




Figure 5.9-7 Folder in USB flash drive




Figure 5.9-8 Select the.obj file




Figure 5.9-9 Input password

5.10 KDManger

KDManager is an auxiliary software for HMI project upload, download and decompile, HMI firmware update, and obtain HMI system information. It contains 8 processing modules: **[Download Operate]**, **[Upload Operate]**, **[System Operate]**, **[Get Version]**, **[Decompile Operate]**, **[Net Pass Through]**, **[Virtual COM Through]**, **[Bridged Net Pass Through]**, use these processing module is the premise of need MK and PC communication success, and communication type and parameters can be set in the **[Communication Set]** in any page. It is recommended that users communicate by USB-Slave interface without other Settings. HMI or PLC program can be downloaded.




Figure 5.10-1 KDMange initial interface




Figure 5.10-2 Communication Set interface

5.10.1 Download/Upload Operate

After saving the configuration screen edited by KincoDTools, .dpj format file is generated. After compilation, the .pkg , .pkgx file required for HMI is generated . Click[**Download User Data**] and find the.pkg or . pkgx files in the project file saving path, and click [**Open**] to enter the download page.




Figure 5.10-3 Download Operate step1




Figure 5.10-4 Download Operate step2

5.10.2 System Operate




Figure 5.10-5 System Operate interface

Name	Description
GetHMI IP/PORT information	Obtain the IP address and port number of the current HMI WiFi, LAN0, and LAN1
Wi-Fi set	Scan out the currently available WiFi, and set to select the network to be connected
APN set	A parameter that the user must configure when surfing the internet through the HMI, which determines the way the user HMI accesses the mobile network
Set LANIP/PORT	Update the IP address and port number to the set value
Return User Application Status	HMI jumps to run the configuration program

Return Set Application Status	HMI changes to the embedded SETUP interface
Write Firmware	To update the HMI kernel and file system,user need to use this function under the guidance of the manufacturer. Before updating the firmware, user need to back up the configuration engineering and formula data running on the HMI to avoid data loss after the update
Synchronization system time	Synchronize computer time to HMI

5.10.3 Get Version

In the successful communication state, user can directly click [Get Version] to view the HMI firmware version information.




Figure 5.10-6 Get version




Figure 5.10-7 Successfully obtained version information

5.10.4 Decompile Operate

Decompile operate can reverse compile the .pkgx file in the MK to generate a project folder and save it on the computer, and then open KincoDTools for editing.

Operation steps:

1. Select the target .pkg , .pkgx files to be decompiled
2. **Select Decompile Target Project Directory** means to select the storage path of the decompilation project folder;
3. Click [**Decompile**], the password input box will pop up, if no password is set, enter the default password: 888888, click [**OK**] to decompile.




Figure 5.10-8 Select the .pkgx file




Figure 5.10-9 Input password window




Figure 5.10-10 Decompiler successfully

5.10.5 Decrypt Operation

KincoDTools supports data encryption components: trend chart components, XY chart components, and historical data display components. These components continuously collect data during operation, and the collected data (historical data) can be optionally generated into CSV format files and saved to the recipe data area or external storage devices.

Open editing configuration screen, check the **[Encryption]** on the component properties page to encrypt the generated CSV file and protect the security of the collected data information.




Figure 5.10-11 Histotiesl Events Storage interface

After the encrypted CSV file is opened, garbled characters are displayed. You need to click **[Decrypte Historic Data File]** to see the correct data information. What should be noted is:

1. If the encrypted file is changed manually, KDManager [**Decrypte Historic Data File**] will prompt an error, informing the user that the source file is damaged
2. After [**Decrypte Historic Data File**] is performed by KDManager, you can only open and view, but cannot modify and edit CSV files or PDF files

5.10.6 Through communication method

KDManager supports three through communication methods: Net Pass Through, Virtual COM Through, and Bridge Net Pass Through

Net Pass Through: The current communication method needs to be selected as network port. Once pass through is enabled, a connection between HMI and PLC can be established, and PLC software can be used to monitor or download the PLC.

Virtual COM Through: The PC establishes communication with the HMI through the virtual device according to the communication parameters in "PC→HMI Parameter Settings", and the HMI communicates with the PLC through the communication mode in "HMI→PLC parameter Settings", so that the PLC software can be used on the computer to monitor and operate the connected PLC.

Bridge Net Pass Through: The PC is connected to the Intranet of PLC and HMI, so that the PLC program of the remote device can be uploaded, downloaded and monitored.

For detailed , see **KincoDTools user manual** section 8.9~8.11.

6 Services and Support

6.1 Services

Technical Support Hotline

If you have any questions about product selection or usage, you can seek technical support by calling our technical support hotline: 400-700-5281.

Agents and Offices

If you have any questions about the products described in this manual, please contact the local offices and agents of Kinco. For information regarding user training and other matters, please visit the company's website or contact local agents for training plans.

6.2 Contact Us

Kinco(Shanghai) Automation Co., Ltd.

Address: Building 3, No. 26 Qiuyue Road, Zhangjiang High-Tech Park, Shanghai (201203)

Tel: 86-21-68798588

Fax: 86-21-68797688

Email: sales@kinco.cn

Kinco Electric Co., Ltd. Shenzhen Branch

Address: 3rd Floor, Building 1, Yizhongli Industrial Park, No. 6 Langshan 1st Road, North District, High-Tech Park, Nanshan District, Shenzhen (518057)

Tel: 86-755-26585555 (12 lines)

Fax: 86-755-26616372

Email: sales@kinco.cn

7 Appendix

7.1 Fast selection list

Standard type		MK070E-33DT	MK070E-32DX	MK043E-20DT
Switch value	DI	16*DC24V	16*DC24V	9*DC24V
	DO	14*DC24V	4*DC24V 12*Relay	9*DC24V
	DIO	/	/	/
Analog value	AI	2*AI	/	2*A I(support 0-10V signal)
	AO	1*AO	/	/
Download interface	USB-B	√	√	√
	Type-C	×	×	×
	RS485(Port1)	√	√	√
Communication	CAN	1	1	1
	RS485	2	2	2
	RS232	×	×	×
Expansion module		Up to 8 KS expansion module		
Screen size		7’’TFT	7’’TFT	4.3’’TFT
Screen quality	Resolution	800*480		480*272
	Color	256K color		
	Luminance	250 cd/m²		
HMI type		4-wire precision resistance network HMI		
Expansion interface		USB-Host (Extended memory and external device)		
Communication download interface		Ethernet		
		USB-B		
<div>● The DC24V of DI and DO in the table indicate the transistor type. DI supports NPN/PNP input, DO supports only PNP output, and Relay indicates the relay type.</div> <div>● MK model with relay output do not support high-speed pulse output</div> <div>● AI and AO support 4-20mA/1-5V/0-20mA/0-10V signals without special instruction</div>				

MK series integrated(PLC+HMI) user manual

Standard type		MK070E-27DRT	MK043E-20DTC	MK043E-27DT
Switch value	DI	12*DC24V	9*DC24V	10*DC24V
	DO	12*Relay	9*DC24V	10*DC24V
	DIO	/	/	4*DC24V
Analog value	AI	3*RD Support Pt100 thermoelectric resistance, temperature range -40℃ ~ 240 ℃	2*TC Support J/K/E/T thermocouples	2*AI
	AO	/	/	1*AO
Download interface	USB-B	√	√	×
	Type-C	×	×	√
	RS485(Port1)	√	√	√
Communication	CAN	1	1	1
	RS485	2	2	2
	RS232	×	×	1
Expansion module		Up to 8 KS expansion module		
Screen size		7’’TFT	4.3’’TFT	
Screen quality	Resolution	800*480	480*272	
	Color	256K color		
	Luminance	250 cd/m²		
HMI type		4-wire precision resistance network HMI		
Expansion interface		USB-Host (Extended memory and external device)		
Communication download interface		Ethernet		
		USB-B		
<div>● The DC24V of DI and DO in the table indicate the transistor type. DI supports NPN/PNP input, DO supports only PNP output, and Relay indicates the relay type.</div> <div>● MK model with relay output do not support high-speed pulse output</div> <div>● AI and AO support 4-20mA/1-5V/0-20mA/0-10V signals without special instruction</div>				

MK series integrated(PLC+HMI) user manual

Economic type		MK070C-33DT	MK043C-20DT
Switch value	DI	16*DC24V	9*DC24V
	DO	14*Relay	9*DC24V
	DIO	/	/
Analog value	AI	2*AI	2*AI Support 0-10V signal
	AO	1*AO	/
Download interface	USB-B	√	√
	Type-C	×	×
	RS485(Port1)	√	√
Communication	CAN	×	×
	RS485	1	1
	RS232	×	×
Expansion module		NO support	
Screen size		7”TFT	4.3”TFT
Screen quality	Resolution	800*480	480*272
	Color	256K color	
	Luminance	250 cd/m ²	400 cd/m ²
HMI type		4-wire precision resistance network HMI	
Expansion interface		USB-Host	
Communication download interface		NO Ethernet	
		USB-B	
<div>● The DC24V of DI and DO in the table indicate the transistor type. DI supports NPN/PNP input, DO supports only PNP output, and Relay indicates the relay type.</div> <div>● AI and AO support 4-20mA/1-5V/0-20mA/0-10V signals without special instruction</div>			